





1.0kw	1.4kw	1.7kw, 1.9kw	2.2kw
 51-970251 For 1.0kw, CCW OEM:0-001-208-416 Lester:17025	 51-869804 For 1.4kw, CW OEM:0-001-108-031 Lester:16980	 51-970384 For 1.7kw, CW OEM:0-001-110-016,075 Lester:17038,17410	 51-95096 For 2.2kw, CW OEM:0-001-362-700 Lester:17318
	 51-970134 For 1.4kw, CW OEM:0-001-108-012 Lester:17013	 51-95016 For 1.9kw, CW OEM:0-001-354-100,0-001-366-001 Lester:17159	
	 51-970454 For 1.4kw, CW OEM:0-001-108-065,115 Lester:17236	 51-95141 For 1.9kw, CW OEM:0-001-362-072,0-001-366-010 Lester:18370	
	 51-971354 For 1.4kw, CW OEM:0-001-108-030 Lester:17135	 51-95151 For 1.9kw, CW OEM:0-001-366-014 Lester:18467	

51- Drive End Frame

2.4kw	2.4kw	2.4kw	2.5kw
 51-95015 For 2.4kw, CW OEM:0-001-362-051,057 Lester:17127	 51-95143 For 2.4kw, CW OEM:0-001-362-021 Lester:	 51-95156 For 2.4kw, CW OEM:0-001-362-064,301 Lester:17229	 51-95140 For 2.5kw, CW OEM:0-001-362-001,002 Lester:16445,16615
 51-95020 For 2.4kw, CW OEM:0-001-358-047,0-001-362-046 Lester:17112	 51-95146 For 2.4kw, CW OEM:0-001-362-060,085 Lester:	 51-95161 For 2.4kw, CW OEM:0-001-362-063 Lester:17228	
 51-95139 For 2.4kw, CW OEM:0-001-362-040,059,075 Lester:16564	 51-95151 For 2.4kw, CW OEM:0-001-362-074 Lester:		
 51-95142 For 2.4kw, CW OEM:0-001-362-011 Lester:	 51-95152 For 2.4kw, CW OEM:0-001-362-058,0-001-366-003 Lester:		

51- Drive End Frame

2.7kw	2.8kw	3.0kw	3.0kw
 51-95022 For 2.4kw, CW OEM:0-001-362-016,034,305,313 Lester:17075,18027	 51-95147 For 2.8kw, CW OEM:0-001-363-101 Lester:18031	 51-95008 For 3.0kw, CW OEM:0-001-358-049,0-001-359-049 Lester:17074	 51-95043 For 3.0kw, CW OEM:0-001-367-070,302 Lester:18259
 51-95051 For 2.7kw, CW OEM:0-001-354-107,0-001-362-310 Lester:17077		 51-95010 For 3.0kw, CW OEM:0-001-362-312,316 Lester:16563,17095	 51-95079 For 3.0kw, CW OEM:0-001-367-072,0-001-369-007 Lester:17307
 51-95080 For 2.7kw, CW OEM:0-001-362-304 Lester:18236		 51-95035 For 3.0kw, CW OEM:0-001-367-008 Lester:	 51-95082 For 3.0kw, CW OEM:0-001-359-122,0-001-367-029 Lester:17092
 51-95157 For 2.7kw, CCW OEM:0-001-362-321 Lester:17232		 51-95039 For 3.0kw, CW OEM:0-001-359-043,084 Lester:17106,17127	 51-95094 For 3.0kw, CW OEM:0-001-359-038,083,005,113 Lester:17136

51- Drive End Frame

Bosch





3.0kw	3.0kw	3.0kw	3.1kw
 51-95097 For 3.0kw, CW OEM:0-001-367-054 Lester:18035	 51-95157 For 3.0kw, CCW OEM:0-001-367-061 Lester:17308	 51-95164 For 3.0kw, CW OEM:0-001-367-022,0-001-368-027 Lester:18474	 51-95145 For 3.1kw, CW OEM:0-001-369-020 Lester:18372
 51-95107 For 3.0kw, CW OEM:0-001-367-026,073 Lester:18237	 51-95159 For 3.0kw, CW OEM:0-001-367-039 Lester:		 51-95158 For 3.1kw, CW OEM:0-001-369-003 Lester:
 51-95148 For 3.0kw, CW OEM:0-001-365-004 Lester:17076	 51-95160 For 3.0kw, CW OEM:0-001-362-324,0-001-367-015 Lester:18465		
 51-95153 For 3.0kw, CW OEM:0-001-367-021,0-001-368-012 Lester:	 51-95163 For 3.0kw, CW OEM:0-001-367-027 Lester:17074		

4.0kw	5.5kw	9.0kw	
 51-95042 For 4.0kw, CW OEM:0-001-359-021,028 Lester:18029	 51-95025 For 5.5kw, CW OEM:0-001-410-053,099 Lester:17094	 51-95057 For 9.0kw, CW OEM:0-001-510-014,017 Lester:17107	 51-95128 OEM:0-001-362-086 Lester:
 51-95131 For 4.0kw, CW OEM:0-001-359-104,0-001-367-006 Lester:18227			 51-95129 OEM:0-001-367-051 Lester:
 51-95154 For 4.0kw, CW OEM:0-001-368-040 Lester:18254			 51-95130 OEM:0-001-367-063 Lester:
			 51-95137 OEM: Lester:



51- Drive End Frame

Bosch






 51-95138 OEM: Lester:	 51-95155 For CW OEM:0-001-367-006 Lester:18227		
 51-95144 OEM: Lester:	 51-95162 OEM: Lester:		
 51-95149 For CW OEM:0-001-364-101,0-001-365-006 Lester:18028	 51-95167 OEM: Lester:		
 51-95150 OEM:0-001-367-011 Lester:			

1.0kw	1.0kw	1.0kw	1.0kw
 51-866762 For 1.0kw, CW, G/R Starter OEM:028000-696,697 Lester:16676	 51-868251 For 1.0kw, CW, G/R Starter OEM:028000-972,128000-206 Lester:16825	 51-868921 For 1.0kw, CW, G/R Starter OEM:128000-137 Lester:16892	 51-869601 For 1.0kw, CW, G/R Starter OEM:128000-747 Lester:16960
 51-867371 For 1.0kw, CW, G/R Starter OEM:028000-590,756,128000-124 Lester:16737,17520	 51-868281 For 1.0kw, CW, G/R Starter OEM:028000-822 Lester:16828	 51-868938 For 1.0kw, CCW, G/R Starter OEM:128000-347,594,827 Lester:16893	 51-869751 For 1.0kw, CW, G/R Starter OEM:128000-746 Lester:16884
 51-868021 For 1.0kw, CW, G/R Starter OEM:028000-805 Lester:16826	 51-868331 For 1.0kw, CW, G/R Starter OEM:028000-926 Lester:16833	 51-868951 For 1.0kw, CW, G/R Starter OEM:128000-144,228000-432 Lester:16895,17681	 51-870201 For 1.0kw, CW, G/R Starter OEM:128000-350,750 Lester:17020 Note:Conversion from 1.4kw
 51-868211 For 1.0kw, CW, G/R Starter OEM:028000-806,907 Lester:16821	 51-868781 For 1.0kw, CW, G/R Starter OEM:128000-190,563 Lester:16878	 51-869131 For 1.0kw, CW, G/R Starter OEM:128000-028,508,228000-021 Lester:16913	 51-870280 For 1.0kw, CW, G/R Starter OEM:028000-832 Lester:17028

51- Drive End Frame




1.0kw	1.0kw	1.0kw	1.0kw
 51-870281 For 1.0kw, CW, G/R Starter OEM:028000-832,128000-359,995 Lester:17028	 51-871701 For 1.0kw, CCW, G/R Starter OEM:128000-719,831 Lester:17170	 51-872541 For 1.0kw, CW, G/R Starter OEM:128000-570 Lester:17254	 51-874211 For 1.0kw, CW, G/R Starter OEM:128000-457,569,699 Lester:17421
 51-870841 For 1.0kw, CW, G/R Starter OEM:128000-496,527,528 Lester:17084 Note:Conversion from 1.4kw	 51-871711 For 1.0kw, CW, G/R Starter OEM:128000-442,578 Lester:17171	 51-872591 For 1.0kw, CW, G/R Starter OEM:128000-952 Lester:17259	 51-874661 For 1.0kw, CW, G/R Starter OEM:128000-781,228000-339,742 Lester:17466,17573,17785 Note:Conversion from 1.4kw
 51-871421 For 1.0kw, CW, PLGR Starter OEM:128000-621 Lester:17142 Note:Convert 1.4kw to 1.0kw	 51-871971 For 1.0kw, CW, G/R Starter OEM:128000-714,938,228000-047 Lester:17197,17465 Note:Conversion from 1.4kw	 51-872641 For 1.0kw, CW, G/R Starter OEM:128000-721 Lester:17298	 51-874831 For 1.0kw, CW, G/R Starter OEM:228000-110,171 Lester:17495,17483
 51-871431 For 1.0kw, CW, G/R Starter OEM:128000-218 Lester:17143	 51-872031 For 1.0kw, CW, PLGR Starter OEM:128000-740 Lester:17203	 51-874201 For 1.0kw, 1.2kw CW, G/R Starter OEM:128000-558 Lester:17420	 51-875321 For 1.0kw, CW, G/R Starter OEM:128000-269 Lester:17532






51- Drive End Frame

1.0kw	1.2kw	1.2kw	1.2kw
 51-876172 For 1.0kw, CW, G/R Starter OEM:028000-575 Lester:17617	 51-822018 For 1.2kw, CW, G/R Starter OEM: Lester:	 51-872568 For 1.2kw, 1.4kw, CW, G/R Starter OEM:128000-835,836,228000-090,321 Lester:17256,17531,17532	 51-874658 For 1.2kw, CW, G/R Starter OEM:228000-047 Lester:17465
 51-876661 For 1.0kw, CW, G/R Starter OEM:228000-261 Lester:17666	 51-871708 For 1.2kw, CCW, G/R Starter OEM:128000-831 Lester:17170	 51-872858 For 1.2kw, CW, G/R Starter OEM:128000-771 Lester:17285	 51-874878 For 1.2kw, 1.4kw, CW, G/R Starter OEM:128000-979,228000-115,162,252 Lester:17487,17530,17537
	 51-871978 For 1.2kw, 1.4kw, CW, G/R Starter OEM:128000-938 Lester:17197	 51-874608 For 1.2kw, 1.4kw, CCW, G/R Starter OEM:228000-036 Lester:17460	 51-875168 For 1.2kw, 1.4kw, CW, G/R Starter OEM:228000-205,399,720 Lester:17516,17584
	 51-872028 For 1.2kw, 1.4kw, CW, G/R Starter OEM:128000-700,712,878,228000-041 Lester:17202,17204	 51-874648 For 1.2kw, 1.4kw, CW, G/R Starter OEM:128000-975,228000-206 Lester:17464,17517	 51-875348 For 1.2kw, 1.4kw, CCW, G/R Starter OEM:228000-110,171 Lester:17687,17534,17715

51- Drive End Frame






Denso





1.2kw	1.4kw	1.4kw	1.4kw
 51-875368 For 1.2kw, 1.4kw, CW, G/R Starter OEM:228000-257,328,374 Lester:17536,17668	 51-822028 For 1.4kw, CW, G/R Starter OEM:128000-822 Lester:17629	 51-866507 For 1.4kw, CW, G/R Starter OEM:028000-625,783 Lester:16759,17115	 51-867904 For 1.4kw, CW, G/R Starter OEM:028000-927,128000-125 Lester:16790
 51-875718 For 1.2kw, CW, G/R Starter OEM:228000-302 Lester:17562	 51-862367 For 1.4kw, CW, G/R Starter OEM:028000-360,434,847 Lester:16236	 51-866574 For 1.4kw, CW, G/R Starter OEM:128000-071 Lester:16657 Note:For Black Case Type	 51-868234 For 1.4kw, CW, G/R Starter OEM:028000-986 Lester:16823
 51-877278 For 1.2kw, CW, G/R Starter OEM:228000-631,666,774,868 Lester:17727,17737,17793,17794	 51-864294 For 1.4kw, CW, G/R Starter OEM:128000-543 Lester:17129	 51-866577 For 1.4kw, CW, G/R Starter OEM:128000-071 Lester:16657 Note:For Golden Case Type	 51-868294 For 1.4kw, CW, G/R Starter OEM:128000-135 Lester:16829
 51-877748 For 1.2kw, 1.4kw, CCW, G/R Starter OEM:228000-617,627,628 Lester:17774,17777	 51-865787 For 1.4kw, CW, G/R Starter OEM:028000-400,402,451,582 Lester:16578,16674	 51-866578 For 1.4kw, CW, G/R Starter OEM:128000-071 Lester:16657	 51-868318 For 1.4kw, CW, G/R Starter OEM:128000-973,974,228000-289 Lester:16831,17493

1.4kw	1.4kw	1.4kw	1.4kw
 51-868344 For 1.4kw, CW, G/R Starter OEM:028000-938,128000-335 Lester:16834	 51-869604 For 1.4kw, CW, G/R Starter OEM:128000-747 Lester:16960	 51-870204 For 1.4kw, CW, G/R Starter OEM:128000-350 Lester:17020 Note:For Black Case Type	 51-870844 For 1.4kw, CW, G/R Starter OEM:128000-496,527,528 Lester:17084
 51-868844 For 1.4kw, CW, G/R Starter OEM:128000-746 Lester:16884	 51-869784 For 1.4kw, 1.6kw, CCW, G/R Starter OEM:128000-343,348,595,799 Lester:16978	 51-870207 For 1.4kw, CW, G/R Starter OEM:128000-350 Lester:17020 Note:For Golden Case Type	 51-870914 For 1.4kw, CW, G/R Starter OEM:128000-495 Lester:17091
 51-868874 For 1.4kw, CCW, G/R Starter OEM:028000-980,128000-123,720 Lester:16696	 51-870024 For 1.4kw, CW, G/R Starter OEM:128000-534,850 Lester:17002,17256	 51-870277 For 1.4kw, CW, G/R Starter OEM:028000-614 Lester:17027	 51-871007 For 1.4kw, CW, G/R Starter OEM:028000-823,838 Lester:17100,17118
 51-868934 For 1.4kw, CCW, G/R Starter OEM:128000-799,827 Lester:16893,16978	 51-870034 For 1.4kw, CW, G/R Starter OEM:128000-259 Lester:17003	 51-870834 For 1.4kw, CW, G/R Starter OEM:128000-318 Lester:17083	 51-871177 For 1.4kw, CW, G/R Starter OEM:028000-580 Lester:17115

51- Drive End Frame



Denso






1.4kw	1.4kw	1.4kw	1.4kw
 51-871194 For 1.4kw, CW, G/R Starter OEM:028000-839 Lester:17119	 51-872168 For 1.4kw, CW, G/R Starter OEM:128000-750,803,228000-303 Lester:17020,17216,17570	 51-8726998 For 1.4kw, CW, G/R Starter OEM:228000-579 Lester:	 51-873844 For 1.4kw, CW, G/R Starter OEM:128000-177 Lester:17384
 51-871254 For 1.4kw, 1.6kw, CW, G/R Starter OEM:128000-536,556,557,228000-274 Lester:17125,17523	 51-872428 For 1.4kw, CCW, G/R Starter OEM:128000-832,228000-714 Lester:17242	 51-872738 For 1.4kw, CW, G/R Starter OEM:228000-022 Lester:17273	 51-874008 For 1.4kw, CCW, G/R Starter OEM:128000-840 Lester:17263
 51-871897 For 1.4kw, CW, G/R Starter OEM:128000-738 Lester:17189 Note:Conversion from 2.0kw	 51-872554 For 1.4kw, CW, G/R Starter OEM:128000-571 Lester:17255	 51-873744 For 1.4kw, CW, G/R Starter OEM:128000-059 Lester:17374	 51-874228 For 1.4kw, 1.6kw, CW, G/R Starter OEM:128000-820,821,228000-285 Lester:17422,17423,17525
 51-871977 For 1.4kw, CW, G/R Starter OEM:128000-938,228000-047 Lester:17197,17465	 51-872598 For 1.4kw, CW, G/R Starter OEM:128000-930,952 Lester:17259	 51-873747 For 1.4kw, CW, G/R Starter OEM:128000-059 Lester:17374	 51-874238 For 1.4kw, CW, G/R Starter OEM:128000-821,228000-284 Lester:17423,17524

1.4kw	1.4kw	1.4kw	1.4kw
 51-874668 For 1.4kw, CW, G/R Starter OEM:128000-781 Lester:17466	 51-875468 For 1.4kw, CW, G/R Starter OEM:228000-081 Lester:17546	 51-876224 For 1.4kw, CW, G/R Starter OEM:128000-687 Lester:17622	 51-878007 For 1.4kw, CW, G/R Starter OEM:228000-773 Lester:17800
 51-874814 For 1.4kw, CW, G/R Starter OEM:228000-089,170,294,296 Lester:17481,17519	 51-875498 For 1.4kw, CW, G/R Starter OEM:228000-180,340,743 Lester:17549,17574,17788	 51-876718 For 1.4kw, CW, G/R Starter OEM:228000-375,530 Lester:17671	 51-878808 For 1.4kw, CW, G/R Starter OEM:428000-046 Lester:17880
 51-874858 For 1.4kw, CW, G/R Starter OEM:228000-156 Lester:17485	 51-875718 For 1.4kw, CW, G/R Starter OEM:228000-302 Lester:17562	 51-877358 For 1.4kw, CW, G/R Starter OEM:228000-611 Lester:17735	 51-878918 For 1.4kw, CW, G/R Starter OEM:428000-009 Lester:17891
 51-875268 For 1.4kw, CW, G/R Starter OEM:228000-226,642 Lester:17526	 51-875798 For 1.4kw, CW, G/R Starter OEM:128000-811 Lester:17579	 51-877478 For 1.4kw, CW, G/R Starter OEM:228000-703 Lester:17747	

51- Drive End Frame





Denso











1.8kw	2.0kw	2.0kw	
 51-875358 For 1.8kw, 2.0kw, CW, G/R Starter OEM:228000-299,304,409 Lester:17535,17706	 51-840938 For 2.0kw, CW, G/R Starter OEM:428000-093 Lester:	 51-871898 For 2.0kw, CW, G/R Starter OEM:128000-738 Lester:17189 Note:For Conversion Type	
 51-876728 For 1.8kw, CW, G/R Starter OEM:228000-408 Lester:17672	 51-867392 For 2.0kw, CW, G/R Starter OEM:028000-644,700,128000-288 Lester:16739 Note:For Golden Case Core	 51-875818 For 2.0kw, CW, G/R Starter OEM:228000-430,739 Lester:17581,17748	
 51-881988 For 1.8kw, CW, G/R Starter OEM:228000-586 Lester:18198	 51-867397 For 1.4kw, CW, G/R Starter OEM:028000-506 Lester:16739 Note:For Golden Case Type		
	 51-871892 For 2.0kw, CW, G/R Starter OEM:128000-738 Lester:17189 Note:For OEM Type		

1.2kw, 1.4kw, 1.7kw	1.2kw, 1.4kw, 1.7kw	1.2kw, 1.4kw, 1.7kw	2.0kw, 2.2kw
 51-865842 For 1.2kw, CW, G/R Starter OEM:S114-254,254A,254B,254C,254D Lester:16584	 51-868164 For 1.2kw, CCW, G/R Starter OEM:S114-440,475,475A,486 Lester:16816	 51-880512 For 1.2kw, CCW, G/R Starter OEM:S13-94A Lester:18051	 51-880612 For 2.0kw, CW, G/R Starter OEM:S13-92A,104 Lester:18061
 51-867402 For 1.2kw, CW, G/R Starter OEM: Used On:Tilton Racing Car	 51-869862 For 1.2kw, CW, G/R Starter OEM:S114-304,446,453,454 Lester:16986,16997	 51-868174 For 1.4kw, CW, G/R Starter OEM:S114-503,516,516A,528,528A Lester:16817,17196	 51-882992 For 2.2kw, CW, G/R Starter OEM:S13-111,136 Lester:18299
 51-867404 For 1.2kw, 1.4kw CW, G/R Starter Used On:Chevrolet Racing Car	 51-871454 For 1.4kw, CCW, G/R Starter OEM:S114-461,461A Lester:17145	 51-875094 For 1.4kw, CW, G/R Starter OEM:S114-753 Lester:17509	
 51-868142 For 1.2kw, CCW, G/R Starter OEM:S114-441A,441B Lester:16814	 51-874551 For 1.2kw, CW, G/R Starter OEM:S114-701A,701C,806,806A,831 Lester:17455,17246	 51-874767 For 1.7kw, CCW, G/R Starter OEM:S114-755,756,757 Lester:17476,17479	

51- Drive End Frame




Mando And Mitsuba



0.9kw, 1.2kw	1.4kw	1.4kw	1.6kw
 51-871813 For 0.9kw, CW, DD Starter OEM:MC109021 Lester:17181	 51-832224 For 1.4kw, CW, G/R Starter OEM:SM302-22 Lester:17160	 51-842056 For 1.4kw, CW, G/R Starter OEM:SM402-05 Lester:16975	 51-842036 For 1.6kw, CW, G/R Starter OEM:SM402-03 Lester:16960
 51-867293 For 0.9kw, CW, DD Starter OEM:MC107012 Lester:16729	 51-832284 For 1.4kw, CW, G/R Starter OEM:SM302-18,SM302-28 Lester:16845	 51-874744 For 1.4kw, CW, G/R Starter OEM:SM302-44 Lester:17474	
 51-869403 For 0.9kw, CW, DD Starter OEM:MC109032 Lester:17288	 51-842034 For 1.4kw, CW, G/R Starter OEM:SM402-03 Lester:16960		
 51-875034 For 1.2kw, CW, G/R Starter OEM:MP112033,MP112042 Lester:17217	 51-842054 For 1.4kw, CW, G/R Starter OEM:SM402-05 Lester:16975		




0.8kw, 0.9kw	1.2kw	1.2kw	1.2kw
 51-867953 For 0.8kw, CW, DD Starter OEM:M3T10473,M3T10475,M3T10476 Lester:16795	 51-868752 For 1.2kw, CW, G/R Starter OEM:M2T53581 Lester:16875	 51-869394 For 1.2kw, CW, G/R Starter OEM:M1T70481,M1T70482,M1T70483 Lester:16939	 51-871314 For 1.2kw, CW, G/R Starter OEM:M1T71381,M1T71382,M1T72581 Lester:17131
 51-871813 For 0.8kw, CW, G/R Starter OEM:M3T33282 Lester:17181	 51-869004 For 1.2kw, CW, G/R Starter OEM:M1T70985 Lester:16900	 51-869822 For 1.2kw, CW, G/R Starter OEM:M2T53781 Lester:16982	 51-871864 For 1.2kw, CW, G/R Starter OEM:M1T72281,M1T72781 Lester:17161
 51-869663 For 0.9kw, CW, DD Starter OEM:M3T34782,M3T41781 Lester:16966	 51-869314 For 1.2kw, CCW, G/R Starter OEM:M1T70781 Lester:16931	 51-871102 For 1.2kw, CW, G/R Starter OEM:M2T58581,M2T58681,M2T58881 Lester:17110	 51-872174 For 1.2kw, CW, G/R Starter OEM:M1T73381,M1T73383 Lester:17217
	 51-869324 For 1.2kw, CCW, G/R Starter OEM:M1T70881,M1T74181 Lester:16930,16932	 51-871104 For 1.2kw, CW, G/R Starter OEM:M2T58581,M2T58681,M2T58881 Lester:17110	 51-874784 For 1.2kw, CW, G/R Starter OEM:M1T73881 Lester:17478

51- Drive End Frame

Mitsubishi




1.2kw	1.4kw	1.4kw	1.4kw
 51-875644 For 1.2kw, CW, G/R Starter OEM:M1T79481,M1T79482 Lester:17564	 51-869334 For 1.4kw, CW, G/R Starter OEM:M1T71881 Lester:16933	 51-872464 For 1.4kw, CW, G/R Starter OEM:M1T72981A,M1T72985 Lester:17246	 51-875614 For 1.4kw, CW, G/R Starter OEM:M1T78681 Lester:17561
	 51-869984 For 1.4kw, CW, G/R Starter OEM:M1T71081 Lester:16998	 51-874254 For 1.4kw, CW, G/R Starter OEM:M1T60281,M1T60285 Lester:17425	
	 51-871324 For 1.4kw, CW, G/R Starter OEM:M1T71281 Lester:17132,17192	 51-874614 For 1.4kw, CW, G/R Starter OEM:M1T77777 Lester:17461	
	 51-871664 For 1.4kw, CW, G/R Starter OEM:M1T72481,M1T72483,M1T74581 Lester:17166,17266,17194	 51-874694 For 1.4kw, CW, G/R Starter OEM:M1T77381 Lester:17469,17539	







1.4kw, 1.7kw	1.7kw	2.0kw	3.6kw
 51-870464 For 1.4kw, 1.7kw, CW, G/R Starter OEM:M1T73581,M1T74481,M1T74482 Lester:17046	 51-870064 For 1.7kw, CW, G/R Starter OEM:M1T74281,M1T74283,M1T74286 Lester:17006	 51-868532 For 2.0kw, CW, G/R Starter OEM:M2T56181,M2T56182 Lester:16853	 51-870374 For 3.6kw, CW, G/R Starter OEM:M3T90071,M3T90072 Lester:
 51-874704 For 1.4kw, 1.7kw, CCW, G/R Starter OEM:M1T75581,M1T77081 Lester:17470	 51-874674 For 1.7kw, CW, G/R Starter OEM:M1T76081 Lester:17467	 51-882722 For 2.0kw, CW, G/R Starter OEM:M2T56272 Lester:17096	 51-875771 For 3.6kw, CW, G/R Starter OEM:M8T50171 Lester:17577
	 51-877494 For 1.7kw, CW, G/R Starter OEM:M1T84381 Lester:17749		 51-875784 For 3.6kw, CW, G/R Starter OEM:M8T50071 Lester:17578

1.0kw	1.0kw	1.2kw	1.2kw
 5202-8201 For 1.0kw G/R Starter OEM: 028000-591, 128000-190, 527 Lester: 16737, 16891, 17240, 17681	 5202-8242 For 1.0kw G/R Starter OEM: 028000-591, 128000-137, 827 Lester: 16825, 17007, 17251, 17681	 5202-8205 For 1.2kw Silver Body G/R Starter OEM: 128000-714, 938, 228000-047 Lester: 17197, 17465	 5202-8224 For 1.2kw Silver Body G/R Starter OEM: 128000-771, 975 Lester: 17285, 17464
 5202-8202 For 1.0kw G/R Starter OEM: 028000-600, 128000-218, 570 Lester: 16612, 16730, 16913, 17143	 5202-8243 For 1.0kw G/R Starter OEM: 028000-636, 805 Lester: 16826, 16827	 5202-8215 For 1.2kw Silver Body G/R Starter OEM: 228000-082, 226, 275, 642 Lester: 17526, 17687	 5202-8225 For 1.2kw Silver Body G/R Starter OEM: 128000-831 Lester: 17170
 5202-8240 For 1.0kw G/R Starter OEM: 028000-600, 696, 128000-261 Lester: 16612, 16676, 17028, 17666		 5202-8219 For 1.2kw Silver Body G/R Starter OEM: 228000-627 Lester: 17777	 5202-8226 For 1.2kw Silver Body G/R Starter OEM: 228000-090 Lester: 17531
 5202-8241 For 1.0kw G/R Starter OEM: 028000-454, 128000-570 Lester: 16248, 17254		 5202-8223 For 1.2kw Silver Body G/R Starter OEM: 128000-700, 878, 228000-162 Lester: 17202, 17204, 17487, 17537	 5202-8230 For 1.2kw Silver Body G/R Starter OEM: 228000-328, 631 Lester: 17536, 17737

5202 ~ 5251 Commutator End Frame



Denso









1.2kw	1.4kw, 2.0kw	1.4kw	1.4kw
 5202-8234 For 1.2kw Silver Body G/R Starter OEM: Lester:	 5202-8203 For 1.4kw, 2.0kw G/R Starter OEM: 028000-360, 128000-128, 720 Lester: 16251, 16578, 16739, 17547	 5202-8204 For 1.4kw G/R Starter OEM: 128000-350, 496, 527, 528, 750 Lester: 17020, 17084	 5202-8209 For 1.4kw G/R Starter OEM: 128000-259, 556, 228000-274 Lester: 17002, 17003, 17125, 17523
 5202-8244 For 1.0kw G/R Starter OEM: Lester:		 5202-8206 For 1.4kw G/R Starter OEM: 028000-927, 128000-125, 259 Lester: 16790, 17003	 5202-8210 For 1.4kw Silver Body G/R Starter OEM: 128000-284, 714, 821, 938 Lester: 17197, 17423, 17524
		 5202-8207 For 1.4kw Silver Body G/R Starter OEM: 128000-350, 750, 781, 803 Lester: 17020, 17216, 17466, 17573	 5202-8211 For 1.4kw G/R Starter OEM: 128000-135, 348, 564, 595, 799 Lester: 16829, 16978, 17297
		 5202-8208 For 1.4kw Silver Body G/R Starter OEM: 228000-036 Lester: 17460	 5202-8212 For 1.4kw G/R Starter OEM: 128000-348, 595, 746, 799 Lester: 16978

1.4kw	1.4kw	1.4kw	1.4kw
 5202-8213 For 1.4kw G/R Starter CEM: 128000-822, 228000-285 Lester: 17422, 17525	 5202-8220 For 1.4kw Silver Body G/R Starter CEM: 128000-835, 228000-170, 296 Lester: 17265, 17481, 17493, 17519	 5202-8228 For 1.4kw Silver Body G/R Starter CEM: 128000-835, 850, 228000-321 Lester: 17256, 17532	 5202-8235 For 1.4kw Silver Body G/R Starter CEM: 128000-739 Lester: 17400
 5202-8214 For 1.4kw Silver Body G/R Starter CEM: Lester:	 5202-8221 For 1.4kw Silver Body G/R Starter CEM: 128000-556, 979, 228000-252 Lester: 17125, 17202, 17530, 17714	 5202-8229 For 1.4kw Silver Body G/R Starter CEM: 228000-206 Lester: 17517	 5202-8236 For 1.4kw Silver Body G/R Starter CEM: 228000-081 Lester: 17546
 5202-8217 For 1.4kw G/R Starter CEM: 128000-071, 072 Lester: 16657, 17117	 5202-8222 For 1.4kw Silver Body G/R Starter CEM: Lester:	 5202-8232 For 1.4kw Silver Body G/R Starter CEM: 228000-302 Lester: 17562	 5202-8239 For 1.4kw Silver Body G/R Starter CEM: 128000-739, 840, 971, 972 Lester: 17263, 17400
 5202-8218 For 1.4kw G/R Starter CEM: 128000-628 Lester: 17619	 5202-8227 For 1.4kw Silver Body G/R Starter CEM: 228000-022, 205 Lester: 17273, 17516	 5202-8233 For 1.4kw Silver Body G/R Starter CEM: 228000-703 Lester: 17747	 5202-8244 For 1.4kw Silver Body G/R Starter CEM: Lester:

5202 ~ 5251 Commutator End Frame







Denso












1.8kw, 2.0kw	2.5kw, 4.5kw	3.0kw, 5.5kw	
 5202-8238 For 1.8kw Silver Body G/R Starter OEM: Lester:	 5251-8201 For 2.5kw, 4.5kw G/R Starter OEM: 028000-558, 588, 656, 686, 807 Lester: 16523, 16830, 17302	 5231-8201 For 3.0kw, 5.5kw G/R Starter OEM: 128000-049, 256, 422, 491 Lester: 16881, 17215, 17391, 17600	
 5202-8237 For 2.0kw Silver Body G/R Starter OEM: 228000-299, 409 Lester: 17669, 17706, 18004, 18139	 5251-8202 For 2.5kw, 4.5kw G/R Starter OEM: 128000-055, 056 Lester: 16824	 5231-8202 For 3.0kw, 5.5kw G/R Starter OEM: 128000-560, 561, 228000-560 Lester: 17613, 18408	
 5202-8245 For 2.0kw Silver Body G/R Starter OEM: 428000-093 Lester:		 5231-8203 For 3.0kw, 5.5kw G/R Starter OEM: 128000-562, 228000-256 Lester: 17614	

1.0kw	1.2kw	1.2kw	1.2kw, 1.4kw
 5302-8143 1.0kw G/R Starter OEM: 128000-257, 128000-258 Lester: 17007	 5302-8114 1.2kw Silver Body G/R Starter OEM: 228000-642 Lester: 17526 Note: Solenoid Housing 5302-8217	 5302-8134 1.2kw Silver Body G/R Starter OEM: 228000-036 Lester: 17460 Note: Solenoid Housing 5302-8233	 5302-8109 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-756, 835, 228000-170 Lester: 16878, 17256, 17481 Note: Solenoid Housing 5302-8223
 5302-8144 1.0kw G/R Starter OEM: 128000-218 Lester: 17143 Note:	 5302-8120 1.2kw Silver Body G/R Starter OEM: 228000-090 Lester: 17531 Note: Solenoid Housing 5302-8221	 5302-8137 1.2kw Silver Body G/R Starter OEM: 228000-255 Lester: 18199 Note: Solenoid Housing 5302-8235 For Harley-Davidson	 5302-8113 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-700, 712, 878 Lester: 17202, 17204 Note: Solenoid Housing 5302-8213
	 5302-8127 1.2kw Silver Body G/R Starter OEM: 228000-328 Lester: 17536 Note: Solenoid Housing 5302-8230		 5302-8115 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-567, 568 Lester: 17715, 17716 Note: Solenoid Housing 5302-8219
	 5302-8133 1.2kw Silver Body G/R Starter OEM: 228000-764 Lester: 17784 Note: Solenoid Housing 5302-8227		 5302-8118 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-162, 252, 375, 530 Lester: 17530, 17537, 17671, 17707 Note: Solenoid Housing 5302-8215

53- Solenoid Switch Assembly




Denso




1.2kw, 1.4kw	1.2kw, 1.4kw	1.4kw	1.4kw
 5302-8121 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-979, 228000-115 Lester: 17125, 17487 Note: Solenoid Housing 5302-8213	 5302-8138 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-771, 228000-205, 399 Lester: 17285, 17464, 17517, 17584 Note: Solenoid Housing 5302-8237	 5302-8101 1.4kw Silver Body G/R Starter OEM: 128000-781, 228000-180 Lester: 17466, 17549 Note: Solenoid Housing 5302-8214	 5302-8105 1.4kw Silver Body G/R Starter OEM: 228000-742 Lester: 17785 Note: Solenoid Housing 5302-8214
 5302-8125 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-714, 938, 228000-047 Lester: 17197, 17465 Note: Solenoid Housing 5302-8228	 5302-8139 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-627, 628 Lester: 17774 Note: Solenoid Housing 5302-8241	 5302-8102 1.4kw Silver Body G/R Starter OEM: 128000-750 Lester: 17020 Note: Solenoid Housing 5302-8214	 5302-8106 1.4kw Silver Body G/R Starter OEM: 228000-294, 321 Lester: 17519, 17532 Note: Solenoid Housing 5302-8212
 5302-8129 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-831, 832 Lester: 17170, 17242 Note: Solenoid Housing 5302-8232		 5302-8103 1.4kw Silver Body G/R Starter OEM: 128000-803 Lester: 17216 Note: Solenoid Housing 5302-8214	 5302-8107 1.4kw Silver Body G/R Starter OEM: 128000-973, 228000-484, 485 Lester: 16831 Note: Solenoid Housing 5302-8224
 5302-8131 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-631, 666, 774, 868 Lester: 17727 Note: Solenoid Housing 5302-8230		 5302-8104 1.4kw Silver Body G/R Starter OEM: 228000-301, 302, 303, 611 Lester: 17562, 17570, 17571 Note: Solenoid Housing 5302-8225	 5302-8108 1.4kw Silver Body G/R Starter OEM: 228000-339 Lester: 17573 Note: Solenoid Housing 5302-8214




1.4kw	1.4kw	1.4kw	1.4kw
 5302-8110 1.4kw Silver Body G/R Starter OEM: 128000-739,840,971 Lester: 17263 Note: Solenoid Housing 5302-8220	 5302-8117 1.4kw Silver Body G/R Starter OEM: 228000-340 Lester: 17574 Note: Solenoid Housing 5302-8214	 5302-8124 1.4kw Silver Body G/R Starter OEM: 228000-509 Lester: 17714 Note: Solenoid Housing 5302-8223	 5302-8132 1.4kw Silver Body G/R Starter OEM: 128000-821 Lester: 17423 Note: Solenoid Housing 5302-8229
 5302-8111 1.4kw Silver Body G/R Starter OEM: 228000-226 Lester: 17526 Note: Solenoid Housing 5302-8226	 5302-8119 1.4kw Silver Body G/R Starter OEM: 228000-743,773 Lester: 17788 Note: Solenoid Housing 5302-8216	 5302-8126 1.4kw Silver Body G/R Starter OEM: 128000-811 Lester: 17579 Note: Solenoid Housing 5302-8232	 5302-8135 1.4kw Silver Body G/R Starter OEM: 228000-196 Lester: 17529 Note: Solenoid Housing 5302-8239
 5302-8112 1.4kw Silver Body G/R Starter OEM: 228000-289 Lester: 17493 Note: Solenoid Housing 5302-8221	 5302-8122 1.4kw Silver Body G/R Starter OEM: 228000-081 Lester: 17546 Note: Solenoid Housing 5302-8217	 5302-8128 1.4kw Silver Body G/R Starter OEM: 228000-284 Lester: 17524 Note: Solenoid Housing 5302-8231	 5302-8136 1.4kw Silver Body G/R Starter OEM: 228000-022 Lester: 17273 Note: Solenoid Housing 5302-8238
 5302-8116 1.4kw Silver Body G/R Starter OEM: 228000-156 Lester: 17485 Note: Solenoid Housing 5302-8216	 5302-8123 1.4kw Silver Body G/R Starter OEM: 228000-083 Lester: 17534 Note: Solenoid Housing 5302-8222	 5302-8130 1.4kw Silver Body G/R Starter OEM: 228000-257,374,703 Lester: 17668,17700 Note: Solenoid Housing 5302-8230	 5302-8140 1.4kw Silver Body G/R Starter OEM: 128000-930 Lester: 17259 Note: Solenoid Housing 5302-8234

53- Solenoid Switch Assembly

Denso





1.4kw	2.0kw		
 5302-8141 1.4kw Silver Body G/R Starter OEM: 228000-107 Lester: 18175 Note: Solenoid Housing 5302-8242	 5302-8146 2.0kw Silver Body G/R Starter OEM: 228000-739 Lester: 17748 Note:		
 5302-8142 1.4kw G/R Starter OEM: Lester: Note:			
 5302-8145 1.4kw G/R Starter OEM: Lester: Note:			





2.5kw, 4.5kw	2.5kw, 4.5kw	3.0kw, 5.5kw	3.0kw, 5.5kw
 5350-8201 CW G/R Starter OEM: 128000-021, 054, 227, 248, 312 Lester: 16990, 17390, 17394 Note:	 5350-8205 CW G/R Starter OEM: 028000-566 Lester: 16656 Note:	 5330-8201 CW G/R Starter OEM: 128000-245, 274, 228000-500 Lester: 17391, 18155, 18156, 18342 Note: Solenoid Housing 5331-8203	
 5350-8202 CW G/R Starter OEM: 028000-588 Lester: 16658 Note: Solenoid Housing 5351-8205	 5350-8206 CW G/R Starter OEM: 128000-408, 829, 228000-229 Lester: 17399, 17548, 17589, 17630 Note:	 5330-8202 CW G/R Starter OEM: 128000-049, 491, 228000-267 Lester: 16881, 17215, 17306, 17611 Note:	
 5350-8203 CW G/R Starter OEM: 028000-530, 620, 228000-100 Lester: 17286, 17376, 18181, 18190 Note: Solenoid Housing 5351-8203	 5350-8207 CW G/R Starter OEM: 028000-557, 586, 724, 781 Lester: 16614, 16896 Note:	 5330-8203 CW G/R Starter OEM: 128000-491 Lester: 17215 Note:	
 5350-8204 CW G/R Starter OEM: 028000-656 Lester: 17302 Note:	 5350-8208 CW G/R Starter OEM: 128000-829 Lester: 17630 Note:	 5330-8204 CW G/R Starter OEM: Lester: Note:	

Universal Type	1.0kw	1.2kw	1.2kw, 1.4kw
 5302-8201 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-712, 228000-321 Lester: 16831, 17020, 17125, 17707 Note: w/o Hole	 5302-8244 For 1.0kw G/R Starter OEM: 128000-578, 228000-171 Lester: 16833, 17171, 17483	 5302-8227 1.2kw Silver Body G/R Starter OEM: 228000-764 Lester: 17784 Note: Drill Holes from 5302-8202 Assembly is 5302-8133	 5302-8210 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-756, 228000-509 Lester: 16878, 17714 Note: Drill Holes from 5302-8201
 5302-8202 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-714, 228000-284 Lester: 17170, 17465, 17524, 17700 Note: w/o Hole		 5302-8233 1.2kw Silver Body G/R Starter OEM: 228000-036 Lester: 17460 Note: Drill Holes from 5302-8203 Assembly is 5302-8134	 5302-8213 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-700, 712, 878, 979 Lester: 17202, 17204, 17125, 17546 Note: Drill Holes from 5302-8201 Assembly is 5302-8113, 5302-8121
 5302-8203 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-975, 228000-255 Lester: 17259, 17460, 17517, 17584 Note: w/o Hole		 5302-8235 1.2kw Silver Body G/R Starter OEM: 228000-255 Lester: 18199 Note: Drill Holes from 5302-8203 Assembly is 5302-8137	 5302-8215 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-162, 252, 375, 530 Lester: 17530, 17537, 17707, 17671 Note: Drill Holes from 5302-8201 Assembly is 5302-8118
			 5302-8217 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-081, 642 Lester: 17546 Note: Drill Holes from 5302-8201 Assembly is 5302-8114, 5302-8122

5302 ~ 5351 Solenoid Housing










Denso



1.2kw, 1.4kw	1.2kw, 1.4kw	1.2kw, 1.4kw	1.4kw
 5302-8218 1.2kw, 1.4kw Silver Body G/R Starter OEM: Lester: Note: Drill Holes from 5302-8201	 5302-8225 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-301, 302, 303, 611 Lester: 17562, 17570, 17571 Note: Drill Holes from 5302-8201 Assembly is 5302-8104	 5302-8237 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-771, 975, 228000-205 Lester: 17285, 17464, 17517, 17584 Note: Drill Holes from 5302-8203 Assembly is 5302-8138	 5302-8212 1.4kw Silver Body G/R Starter OEM: 228000-294, 321 Lester: 17519, 17532 Note: Drill Holes from 5302-8201 Assembly is 5302-8106
 5302-8219 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-567, 568 Lester: 17715, 17716 Note: Drill Holes from 5302-8201 Assembly is 5302-8115	 5302-8228 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-714, 938, 228000-047 Lester: 17197, 17465 Note: Drill Holes from 5302-8202 Assembly is 5302-8125	 5302-8241 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-627, 628 Lester: 17774 Note: Drill Holes from 5302-8203 Assembly is 5302-8139	 5302-8214 1.4kw Silver Body G/R Starter OEM: 128000-750, 228000-180, 742 Lester: 17020, 17466, 17573, 17785 Note: Drill Holes from 5302-8201 Assembly is 5302-8101, 5302-8102, 5302-8103, 5302-8105, 302-8108, 5302-8117
 5302-8221 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-099, 289 Lester: 17493, 17531 Note: Drill Holes from 5302-8201 Assembly is 5302-8120	 5302-8230 1.2kw, 1.4kw Silver Body G/R Starter OEM: 228000-257, 328, 631, 774, 868 Lester: 17536, 17700, 17727, 17737 Note: Drill Holes from 5302-8202 Assembly is 5302-8127, 5302-8130, 5302-8131		 5302-8216 1.4kw Silver Body G/R Starter OEM: 228000-156, 743, 773 Lester: 17485 Note: Drill Holes from 5302-8201 Assembly is 5302-8116, 5302-8119
 5302-8223 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-756, 835, 228000-170 Lester: 16878, 17256, 17481, 17714 Note: Drill Holes from 5302-8201 Assembly is 5302-8109, 5302-8124	 5302-8232 1.2kw, 1.4kw Silver Body G/R Starter OEM: 128000-811, 831, 832 Lester: 17170, 17242, 17579 Note: Drill Holes from 5302-8202 Assembly is 5302-8129, 5302-8126		 5302-8222 1.4kw Silver Body G/R Starter OEM: 128000-739, 840, 971 Lester: 17263 Note: Drill Holes from 5302-8201 Assembly is 5302-8110

1.4kw	1.4kw	1.4kw	2.0kw
 5302-8224 1.4kw Silver Body G/R Starter OEM: 128000-973, 228000-484, 485 Lester: 16831 Note: Drill Holes from 5302-8201 Assembly is 5302-8107	 5302-8234 1.4kw Silver Body G/R Starter OEM: 128000-930 Lester: 17259 Note: Drill Holes from 5302-8203 Assembly is 5302-8140	 5302-8243 1.4kw G/R Starter OEM: Lester: Note:	 5302-8245 2.0kw Silver Body G/R Starter OEM: 228000-304, 228000-430 Lester: 17535, 17581
 5302-8226 1.4kw Silver Body G/R Starter OEM: 228000-226 Lester: 17526 Note: Drill Holes from 5302-8201 Assembly is 5302-8111	 5302-8238 1.4kw Silver Body G/R Starter OEM: 228000-022 Lester: 17273 Note: Drill Holes from 5302-8203 Assembly is 5302-8136	 5302-8248 1.4kw G/R Starter OEM: Lester: Note:	 5302-8246 2.0kw Silver Body G/R Starter OEM: Lester: Note:
 5302-8229 1.4kw Silver Body G/R Starter OEM: 128000-821 Lester: 17423 Note: Drill Holes from 5302-8202 Assembly is 5302-8132	 5302-8239 1.4kw Silver Body G/R Starter OEM: 228000-196 Lester: 17197, 17465 Note: Drill Holes from 5302-8203 Assembly is 5302-8135		
 5302-8231 1.4kw Silver Body G/R Starter OEM: 228000-284 Lester: 17524 Note: Drill Holes from 5302-8202 Assembly is 5302-8128	 5302-8242 1.4kw Silver Body G/R Starter OEM: 228000-107 Lester: 18175 Note: Drill Holes from 5302-8203 Assembly is 5302-8141		

5302 ~ 5351 Solenoid Housing

(Heavy Duty) Denso


2.5kw, 4.5kw	2.5kw, 4.5kw	2.5kw, 4.5kw	3.0kw, 5.5kw
 5351-8201 2.5kw, 4.5kw G/R Starter OEM: Lester: Note:	 5351-8205 2.5kw, 4.5kw G/R Starter OEM: 028000-588 Lester: 16658 Note: Assembly is 5350-8202	 5351-8209 2.5kw, 4.5kw G/R Starter OEM: Lester: Note:	 5331-8201 3.0kw, 5.5kw G/R Starter OEM: 128000-562 Lester: 17614 Note:
 5351-8202 2.5kw, 4.5kw G/R Starter OEM: Lester: Note:	 5351-8206 2.5kw, 4.5kw G/R Starter OEM: 028000-556, 128000-054, 248 Lester: 16990, 17390, 17394 Note: Assembly is 5350-8201		 5331-8202 3.0kw, 5.5kw G/R Starter OEM: 228000-560, 561 Lester: 18405, 18408 Note:
 5351-8203 2.5kw, 4.5kw G/R Starter OEM: 128000-056 Lester: 16824 Note: Assembly is 5350-8203	 5351-8207 2.5kw, 4.5kw G/R Starter OEM: 028000-840 Lester: 17362 Note:		 5331-8203 3.0kw, 5.5kw G/R Starter OEM: 128000-049, 256 Lester: 16881, 17391 Note: Assembly is 5330-8201
 5351-8204 2.5kw, 4.5kw G/R Starter OEM: Lester: Note:	 5351-8208 2.5kw, 4.5kw G/R Starter OEM: Lester: Note:		

Drive	Drive	Drive	Drive (Heavy Duty)
 5400-8201 9T, CW For 1.2kw,1.4kw Silver Body G/R Starter OEM:128000-712,228000-284 Lester:17204,17524 Dim:29mm Gear OD x 83mm OAL	 5400-8205 9T, CW For 1.4kw G/R Starter OEM: Lester: Dim:29mm Gear OD	 5400-8210 9T, CCW For 1.4kw G/R Starter OEM:128000-283,970 Lester:16839 Dim:29mm Gear OD	 5450-8201 12T, CW For 2.5kw,4.5kw G/R Starter OEM:128000-862,864,228000-027,160 Lester:18197 Dim:44.5mm Gear OD,Pinion Gear 5451-8201
 5400-8202 10T, CW For 1.2kw,1.4kw Silver Body G/R Starter OEM:228000-036,047,611 Lester:17460,17465,17735 Dim:28mm Gear OD x 83mm OAL	 5400-8206 13T, CCW For 1.0kw,1.4kw G/R Starter OEM:128000-347,348,594,595,799 Lester:16893,16978 Dim:41mm Gear OD	 5400-8211 9T, CW For 1.4kw Silver Body G/R Starter OEM:128000-714,832 Lester:17242 Dim:29mm Gear OD	5450-8202 13T, CW For 2.5kw,4.5kw G/R Starter OEM:128000-054,227,228000-195,229 Lester:16658,16990,17548,17600 Dim:39.5mm Gear OD,Pinion Gear 5451-8202 5450-8203 10T, CW For 2.5kw,3.0kw,4.5kw G/R Starter OEM:128000-225,724,228000-238,738 Lester:17353,17613,17633,18190 Dim:40.5mm Gear OD,Pinion Gear 5451-8203
 5400-8203 11T, CW For 1.2kw,1.4kw Silver Body G/R Starter OEM:128000-714,750,803,938 Lester:17020,17197,17216,17570 Dim:29mm Gear OD x 83mm OAL	 5400-8207 11T, CW For 1.4kw Silver Body G/R Starter (Long) OEM:228000-180,340 Lester:17549,17574 Dim:33.5mm Gear OD		5450-8204 11T, CW For 2.5kw G/R Starter OEM:028000-641 Lester:17377 Dim:34.5mm Gear OD,Pinion Gear 5451-8204
 5400-8204 10T, CW For 1.4kw Silver Body G/R Starter OEM:128000-781,228000-156,339 Lester:17466,17485,17573 Dim:33mm Gear OD x 83mm OAL	 5400-8209 13T, CCW For 1.4kw G/R Starter OEM:228000-022 Lester:17273 Dim:29mm Gear OD		5450-8205 11T, CW For 2.5kw,4.5kw G/R Starter OEM:028000-840 Lester:17362 Dim:34.5mm Gear OD,Pinion Gear 5451-8205 5450-8206 11T, CW For 2.5kw,3.0kw G/R Starter OEM:028000-530,620,128000-097,100 Lester:17286,17292,17311,17376 Dim:40.0mm Gear OD,Pinion Gear 5451-8206
			5450-8207 12T, CW For 2.5kw,4.5kw G/R Starter OEM: Lester: Dim:43.5mm Gear OD,Pinion Gear 5451-8207

5400-,5401- Drive And Clutch Assembly



Denso

Drive (Heavy Duty)	Drive (Heavy Duty)	Clutch	
5450-8208 11T, CW For 2.5kw G/R Starter OEM:128000-996,997,228000-019 Lester:17357 Dim:38.0mm Gear OD,Pinion Gear 5451-8208	5450-8216 11T, CW For 2.5kw,4.5kw G/R Starter OEM:028000-621,780,863 Lester:16882 Dim:40.0mm Gear OD,Pinion Gear 5451-8216		
5450-8209 11T, CW For 2.5kw G/R Starter OEM:028000-606 Lester: Dim:41.5mm Gear OD,Pinion Gear 5451-8209	5450-8217 9T, CW For 2.5kw,4.5kw G/R Starter OEM:028000-500,773,128000-686 Lester:16651,17359 Dim:35.5mm Gear OD,Pinion Gear 5451-8217	5401-8201 CW,10-SPL For 1.4kw G/R Starter OEM:228000-022,180,340 Lester:17273,17549,17574 Dim:80mm OAL	
5450-8210 13T, CW For 2.5kw,4.5kw G/R Starter OEM: Lester: Dim:45.5mm Gear OD,Pinion Gear 5451-8210	5450-8218 9T, CW For 2.5kw,4.5kw G/R Starter OEM: Lester: Dim:Pinion Gear 5451-8218		
5450-8211 13T, CW For 5.5kw G/R Starter OEM: Lester: Dim:46.5mm Gear OD,Pinion Gear 5451-8211		5401-8202 CW,10-SPL For 1.0kw,1.2kw,1.4kw G/R Starter OEM:128000-190,700,228000-047,284,631 Lester:16831,17259,17533,17706,17774 Dim:52mm OAL	
5450-8212 15T, CW For 2.5kw,4.5kw G/R Starter OEM:028000-566,128000-079 Lester:16656 Dim:44.0mm Gear OD,Pinion Gear 5451-8212			
5450-8213 9T, CW For 2.5kw,4.5kw G/R Starter OEM:028000-353 Lester:17284 Dim:32.0mm Gear OD,Pinion Gear 5451-8213		5401-8203 CCW,10-SPL For 1.0kw,1.2kw,1.4kw G/R Starter OEM:128000-831,971,228000-465,568 Lester:16888,17170,17400,17716 Dim:80.5mm OAL	
5450-8214 9T, CW For 2.5kw,4.5kw G/R Starter OEM: Lester: Dim:35.5mm Gear OD,Pinion Gear 5451-8214			
5450-8215 12T, CW For 2.5kw G/R Starter OEM: Lester: Dim:37.0mm Gear OD,Pinion Gear 5451-8215		5401-8204 CCW,10-SPL For 1.4kw G/R Starter OEM:128000-832,228000-714 Lester:17242 Dim:52mm OAL	

Drive	Drive	Clutch	Clutch
 5400-8101 9T, CW,12-SPL For 1.2kw,1.4kw,2.0kw G/R Starter OEM:S13-62,S114-253,254,374,403,457 Lester:16584,16740,16813,17104 Dim:32.5mm Gear OD x 69mm L	 5400-8105 9T, CW,5-SPL For 0.8kw DD Starter OEM:S114-396,396D,614 Lester:16843,16912 Dim:29.0mm Gear OD x 78mm L	 5401-8101 CW,10-SPL For DD Starter OEM:S114-396,396D,614 Lester:16843,16912 Dim:12.5mm ID x 29mm Gear OD x 78mm L	
 5400-8102 9T, CW,10-SPL For 2.0kw G/R Starter OEM:S13-84,89A,89B,289,289A Lester:17088 Dim:32.5mm Gear OD x 87mm L	 5400-8106 8T, CCW,10-SPL For 1.2kw G/R Starter OEM:S114-440,475A,486 Lester:16816,17178 Dim:28.0mm Gear OD x 94mm L	 5401-8105 CW,10-SPL For G/R Starter OEM: Lester: Dim:62mm OAL	
 5400-8103 9T, CW,10-SPL For 2.0kw G/R Starter OEM:S13-91 Lester:17018,17138 Dim:25.5mm Gear OD x 87mm L	 5400-8107 21T, CCW,10-SPL For 1.2kw,1.4kw G/R Starter OEM:S114-430A,439,461,484 Lester:16806,16807,17069,17145 Dim:60.0mm Gear OD x 78mm L		
 5400-8104 9T, CW,10-SPL For 1.2kw,1.4kw,2.0kw G/R Starter OEM:S13-65,69,102,104,S114-357A,482 Lester:16733,16772,16809 Dim:35.5mm Gear OD x 87mm L	 5400-8108 8T, CW,10-SPL For 1.2kw G/R Starter OEM:S114-252,322,322A,393 Lester:16694,16803,16982 Dim:28.0mm Gear OD x 87mm L		

5400-,5401- Drive And Clutch Assembly



Mitsubishi

Drive	Drive	Clutch	
 5400-8301 13T, CW,10-SPL For 2.4kw G/R Starter OEM:M3T90072 Lester:17037 Dim:40.0mm Gear OD x 109mm L	 5400-8305 8T, CCW,4-SPL For 0.8kw DD Starter OEM:M3T33081 Lester:17010 Dim:28.0mm Gear OD x 56mm L	 5401-8301 CW,18-SPL For 1.2kw,1.4kw,1.8kw G/R Starter OEM:M2T50371,M2T53085,M2T58881 Lester:16584,16733,17110,17172 Dim:109mm/124mm	
 5400-8302 13T, CW,10-SPL For 2.4kw G/R Starter OEM:M3T90071 Lester:17037 Dim:40.0mm Gear OD x 92mm L	 5400-8306 9T, CW,8-SPL For 1.2kw G/R Starter OEM:M1T60381 Lester: Dim:29.5mm Gear OD x 78mm L	 5401-8302 CW,18-SPL For 1.4kw G/R Starter OEM:M2T58381,M2T58481 Lester:16935 Dim:109mm/124mm	
 5400-8303 9T, CW,8-SPL For 1.7kw G/R Starter OEM:M1T72481,M1T74581 Lester:17166,17194,17206 Dim:29.5mm Gear OD x 51mm L	 5400-8307 10T, CW,8-SPL For 1.4kw,1.6kw G/R Starter OEM:M1T77781,M1T78581,M1T84181 Lester:17461,17559,17561,17726 Dim:28.0mm Gear OD x 51mm L	 5401-8303 CW,20-SPL For 2.0kw,2.2kw G/R Starter OEM:M2T54371,M2T60071,M3T66572 Lester:16744,16799,17008 Dim:117mm/135mm	
 5400-8304 10T, CW,8-SPL For 1.2kw,1.4kw G/R Starter OEM:M1T70985,M1T71281,M1T79681 Lester:16900,17132,17469,17765 Dim:31.5mm Gear OD x 51mm L	 5400-8308 8T, CW,8-SPL For 0.9kw DD Starter OEM: Lester:16514,16794,17181,17684 Dim:28.0mm Gear OD x 55mm L		

9 Tooth	9 Tooth	9 Tooth	10 Tooth
 5402-8203 9T, CW-CCW, 18-SPL For G/R Starter OEM:128000-739,821,228000-257,666 Lester:17263,16823,17423,17668,17727 Dim:29mm Gear OD x 23.5mm L	 5402-8216 9T, CW, 18-SPL For G/R Starter OEM:228000-022 Lester:17273 Dim:29mm Gear OD x 25mm L	 5402-8223 9T, CW-CCW, 18-SPL For G/R Starter OEM: Lester: Dim:33.5mm Gear OD x 23.5mm L	 5402-8206 10T, CW, 18-SPL For G/R Starter OEM:128000-347,348,594,595,799 Lester:17084,17466,17485,17573 Dim:33mm Gear OD x 25mm L
 5402-8205 9T, CW, 18-SPL For G/R Starter OEM:028000-506,128000-096,110,288 Lester:16739 Dim:32.5mm Gear OD x 23.5mm L	 5402-8218 9T, CW, 18-SPL For G/R Starter OEM:128000-283,746,228000-504,720 Lester:16839,17494,17516,17584 Dim:29mm Gear OD x 25mm L		 5402-8207 10T, CW, 18-SPL For G/R Starter OEM:028000-823,128000-105,177,297 Lester:17100 Dim:39mm Gear OD x 23.5mm L
 5402-8209 9T, CW-CCW, 18-SPL For G/R Starter OEM: Lester: Dim:36.5mm Gear OD x 23.5mm L	 5402-8219 9T, CCW, 18-SPL For G/R Starter OEM:128000-283,746,228000-226,642 Lester:16676,17007,17197,17570 Dim:29mm Gear OD x 25mm L		 5402-8208 10T, CW, 18-SPL For G/R Starter OEM: Lester: Dim:
 5402-8211 9T, CW, 18-SPL For G/R Starter OEM:128000-057,074,228,228000-014 Lester:17373,17375 Dim:33.5mm Gear OD x 23.5mm L	 5402-8221 9T, CW-CCW, 18-SPL For G/R Starter OEM:128000-283,228000-205,339,720 Lester:16839,16884,17516,17584 Dim:29mm Gear OD x 29mm L		 5402-8212 10T, CW, 18-SPL For G/R Starter OEM:228000-036,047,611 Lester:17460,17465,17735 Dim:28mm Gear OD x 25mm L




5402 ~ 5451 Pinion Gear

Denso

11 Tooth	13 Tooth	15 Tooth	15 Tooth
 5402-8201 11T, CW, 18-SPL For G/R Starter OEM:028000-626,128000-750,803,938 Lester:16676,17007,17197,17570 Dim:29mm Gear OD x 23.5mm L	 5402-8204 13T, CCW, 18-SPL For G/R Starter OEM:128000-347,348,594,595,799 Lester:16893,16978 Dim:41mm Gear OD x 23.5mm L	 5402-8224 9T, CCW, 18-SPL For G/R Starter OEM: Lester: Dim:29mm Gear OD x 23.5mm L	
 5402-8213 11T, CW, 4-SPL For G/R Starter OEM: Lester: Dim:34.5mm Gear OD x 61mm L			
 5402-8220 11T, CW, 18-SPL For G/R Starter OEM:228000-180,340 Lester:17549,17574 Dim:33.5mm Gear OD x 23.5mm L			


Denso (Heavy Duty)





5402 ~ 5451 Pinion Gear

9 Tooth	10 Tooth	11 Tooth	11 Tooth
 5451-8213 9T, CW, 16-SPL For G/R Starter OEM:028000-353 Lester:17284 Dim:32mm Gear OD x 40mm L	 5451-8203 10T, CW, 16-SPL For G/R Starter OEM:028000-329,588,128000-562 Lester:16635,17614 Dim:40.5mm Gear OD x 36mm L	 5451-8204 11T, CW, 16-SPL For G/R Starter OEM:028000-641 Lester:17377 Dim:34.5mm Gear OD x 40mm L	 5451-8209 11T, CW, 16-SPL For G/R Starter OEM:028000-606 Lester: Dim:41.5mm Gear OD x 40mm L
 5451-8214 9T, CW, 16-SPL For G/R Starter OEM:0-21000-4931,4933,4934 Lester:18193 Dim:35.5mm Gear OD x 40mm L		 5451-8205 11T, CW, 16-SPL For G/R Starter OEM:028000-840 Lester:18197 Dim:34.5mm Gear OD x 40mm L	 5451-8216 11T, CW, 16-SPL For G/R Starter OEM:028000-621,780,863 Lester:16882 Dim:40mm Gear OD x 40mm L
 5451-8217 9T, CW, 16-SPL For G/R Starter OEM:028000-500,773 Lester:16651,17359 Dim:35.5mm Gear OD x 36mm L		 5451-8206 11T, CW, 16-SPL For G/R Starter OEM:028000-530,557,128000-410 Lester:16681,16910,16911,16967 Dim:40mm Gear OD x 36mm L	
		 5451-8208 11T, CW, 16-SPL For G/R Starter OEM:128000-996,997,228000-019 Lester:17357 Dim:38mm Gear OD x 36mm L	

5402 ~ 5451 Pinion Gear

Denso (Heavy Duty)


12 Tooth	13 Tooth	15 Tooth	
 5451-8201 12T, CW, 16-SPL For G/R Starter OEM:128000-862,864,228000-161 Lester:18197 Dim:44.5mm Gear OD x 36mm L	 5451-8202 13T, CW, 16-SPL For G/R Starter OEM:028000-588,128000-021,227 Lester:16658,16830,16990 Dim:39.5mm Gear OD x 36mm L	 5451-8212 15T, CW, 16-SPL For G/R Starter OEM:028000-566,128000-079 Lester: Dim:44mm Gear OD x 40mm L	
 5451-8207 12T, CW, 16-SPL For G/R Starter OEM: Lester: Dim:43.5mm Gear OD x 36mm L	 5451-8210 13T, CW, 16-SPL For G/R Starter OEM: Lester: Dim:45.5mm Gear OD x 36mm L		
 5451-8215 12T, CW, 16-SPL For G/R Starter OEM: Lester: Dim:37mm Gear OD x 35.5mm L	 5451-8211 13T, CW, 16-SPL For G/R Starter OEM: Lester: Dim:46.5mm Gear OD x 36mm L		

8 Tooth	9 Tooth	21 Tooth	25 Tooth
 5402-8102 8T, CW, 10-SPL For G/R Starter OEM:S114-252C,252E,252F,322,322A Lester:16694,16803,16982 Dim:28mm Gear OD x 87mm L	 5402-8101 9T, CW, 10-SPL For G/R Starter OEM:S13-91 Lester:17018,17138 Dim:25.5mm Gear OD x 87mm L	 5402-8106 21T, CCW, 10-SPL For G/R Starter OEM:S114-430A,439,461,484 Lester:16806,16807,17069,17145 Dim:60mm Gear OD x 78mm L	 5402-8107 25T, CCW, 10-SPL For G/R Starter OEM:S114-441A,441B Lester:16814 Dim:70.5mm Gear OD x 76mm L
 5402-8103 8T, CCW, 10-SPL For G/R Starter OEM:S114-440,475A,486 Lester:16816,17178 Dim:28mm Gear OD x 94mm L	 5402-8105 9T, CW, 10-SPL For G/R Starter OEM:S13-47A,50,56,65,69,S114-367,482 Lester:16733,16772,16809 Dim:35.5mm Gear OD x 87mm L		

5402 ~ 5451 Pinion Gear

Mitsubishi




12 Tooth	13 Tooth		
 5402-8301 12T, CW, 20-SPL For G/R Starter OEM:M2T60071,M2T60072,M2T60073 Lester:16744,16799 Dim:36mm Gear OD x 18mm L  5402-8302 12T, CW, 20-SPL For G/R Starter OEM:M8T50071,M8T50171,M8T50172 Lester:17577,17578 Dim:44.5mm Gear OD x 36mm L	 5402-8303 13T, CW, 20-SPL For G/R Starter OEM:M2T54371,M3T66072,M3T66074 Lester:16744,16799 Dim:39.5mm Gear OD x 18.5mm L		

Pinion Gear Kits	Pinion Gear Kits	Pinion Gear Kits	
 5403-8201 OEM:228000-036,047,611 Lester:17460,17465,17735 Components:5402-8212 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate	 5403-8207 OEM:128000-283,746,228000-226,642 Lester:16839,16884,17494,17516,17584 Components:5402-8219 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate	 5403-8212 OEM:228000-022 Lester:17273 Components:5402-8216 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate	
 5403-8202 OEM:128000-347,348,594,595,799 Lester:16893,16978 Components:5402-8204 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate	 5403-8208 OEM:028000-986,128000-739,840,841,971 Lester:16823,17263,17423,17668,17727 Components:5402-8203 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate		
 5403-8204 OEM:028000-626,128000-750,803,938 Lester:16676,17007,17197,17570 Components:5402-8201 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate	 5403-8209 Components:5402-8218 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate		
 5403-8205 OEM:128000-347,348,594,595,799 Lester:17084,17466,17485,17573 Components:5402-8206 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate	 5403-8211 OEM:028000-573,580,128000-071,072 Lester:16657,17117 Components:5402-8215 Pinion Gear 7605-8201 Retaining Ring 7606-8201 Stop Collar 5406-8203 Spring-Pinion Gear 7605-8202 Gear Plate		

5403- ~ 5409- Drive Parts



Shaft	Shaft	Sleeve	Sleeve
 5404-8201 CW For Denso 1.2kw,1.4kw Silver Body G/R Starter OEM:128000-714,938 Lester:17197 Dim:83mm L	 5404-8207 CW For Denso 1.0kw, 1.4kw G/R Starter Dim:83mm L Thread:1/4-20	 5405-8201 CW For Denso 1.2kw,1.4kw Silver Body G/R Starter OEM:128000-714,938 Lester:17197 Dim:52.5mm L	 5405-8205 For Denso G/R Starter OEM: Lester: Dim:74mm L
 5404-8203 CW For Denso 1.0kw, 1.4kw G/R Starter OEM:128000-348,595,799 Lester:16978 Dim:102mm L	 5404-8208 CW For Denso 1.0kw, 1.4kw G/R Starter Dim:83mm L Thread:10-32	 5405-8202 CW (Long) For Denso 1.2kw,1.4kw Silver Body G/R Starter OEM: Lester: Dim:80.5mm L	 5433-8201 For Denso 2.5kw,3.0kw,4.5kw,5.5kw G/R Starter OEM: Lester: Dim:91.8mm L
 5404-8204 CCW For Denso 1.2kw,1.4kw Silver Body G/R Starter OEM: Lester: Dim:83mm L	 5432-8201 CW For Denso 2.5kw,3.0kw,4.5kw,5.5kw G/R Starter OEM: Lester: Dim:145.8mm L	 5405-8203 For Denso 1.4kw G/R Starter OEM: Lester: Dim:90.6mm L	
 5404-8205 CW For Denso 1.4kw G/R Starter OEM:128000-687 Lester:17622 Dim:112.7mm L		 5405-8204 CW (Long) For Denso 1.2kw,1.4kw Silver Body G/R Starter OEM: Lester: Dim:80.5mm L	

5403- ~ 5409- Drive Parts

Spring	Spring	Idle Gear	Idle Gear
 5406-8201 Drive Shaft For Denso G/R Starter Dim:16.2mm OD x 61mm L x 1.2mm Wire Dia.	 5431-8201 Clutch Roller For Denso G/R Starter Dim:5.3mm OD x 15mm L x 0.7mm Wire Dia.	 5408-8201 For Denso 1.2kw,1.4kw Silver Body G/R Starter Dim:26T 11.5mm Tooth Length	 5408-8205 For Denso 1.4kw G/R Starter Dim:12T 18.9mm Gear OD x 13.82mm L
 5406-8202 Clutch Roller For Denso 1.0kw,1.2kw,1.4kw,1.8kw, 2.0kw G/R Starter Dim:6.3mm x 12mm x 14.5mm L 0.7mm Wire Dia.	 5431-8202 Drive Shaft For Denso G/R Starter Dim:19.4mm OD x 92mm L x 1.3mm Wire Dia.	 5408-8202 For Denso 1.4kw G/R Starters Dim:27T 22mm ID x 44.65mm Gear OD x 14mm L	 5413-8201 For Denso 2.5kw,4.5kw G/R Starter Dim:49.5mm Gear OD x 17.3mm L
 5406-8203 Press Plunger For Denso G/R Starter Dim:16.5mm OD x 11mm L x 1.5mm Wire Dia.	 5431-8203 Press Plunger For Denso G/R Starter Dim:15mm OD x 17.3mm L x 1.8mm Wire Dia.	 5408-8203 For Denso 1.0kw,1.4kw,2.0kw G/R Starter Dim:26T 22mm ID x 35mm Gear OD x 13.86mm L	 5413-8202 For Denso 3.0kw,5.5kw G/R Starter Dim:50.5mm Gear OD x 17.3mm L
 5406-8204 Clutch Roller For Hitachi OSGR; Mitsuba OSGR, PMOSGR Starter Dim:5mm x 12.5mm x 12.7mm L 0.76mm Wire Dia.	 5431-8204 Clutch Roller For Denso 2.5kw,3.0kw,4.5kw,5.5kw G/R Starter Dim:19.4mm OD x 92mm L x 1.3mm Wire Dia.	 5408-8204 For Denso G/R Starter Dim:12T, 21-SPL, 22mm Gear OD x 24mm L	

5403- ~ 5409- Drive Parts

Miscellaneous	Miscellaneous		
 5409-8201 Clutch Cap For Mitsubishi Drive Dim:35.5mm ID x 45.4mm OD x 19.2mm L	 5409-8205 Clip - Drive Retaining Ring for Mitsuba OSGR Starter Dim:35.5mm ID x 45.4mm OD x 19.2mm L		
 5409-8202 Clutch Cap For Mitsubishi Drive Dim:31mm ID x 48mm OD x 20mm L			
 5409-8203 Retaining Cap For Mitsuba SM302 Series OSGR; SM402 Series PMOSGR Starter			
 5409-8204 Retainer Plate Retainer for Mitsubishi OSGR Starter Dim:27mm ID x 46mm OD x 6mm H			

1.0kw, 1.2kw	1.4kw	1.8kw, 2.0kw	2.5kw, 4.5kw
 5700-8205 1.0kw G/R Starter Dim: 68mm OD x 53mm L	 5700-8201 1.4kw Silver Body G/R Starter Dim: 76mm OD x 62.4mm L	 5700-8204 2.0kw Early Type G/R Starter Dim: 76mm OD x 114mm L Note: w/C.E.Frame	 5750-8201 2.5kw 12V G/R Starter Note: For Heavy Duty
 5700-8206 1.2kw Silver Body G/R Starter Dim: 76mm OD x 42mm L	 5700-8202 1.4kw Silver Body G/R Starter Dim: 76mm OD x 50mm L Note: w/2 Stud	 5700-8208 1.8kw Silver Body G/R Starter Dim: 78mm OD x 60mm L	 5750-8202 4.5kw 24V G/R Starter Note: For Heavy Duty
	 5700-8203 1.4kw G/R Starter Dim: 76mm OD x 67mm L	 5700-8209 2.0kw Early Type G/R Starter Dim: 78mm OD x 68mm L	
	 5700-8207 1.2kw Silver Body G/R Starter Dim: 76mm OD x 50mm L		

5700 ~ 5750 Field Coil Assembly

Denso

3.0kw, 5.5kw			
 5730-8201 3.0kw 12V G/R Starter Note: For Heavy Duty			
 5730-8202 5.5kw 24V G/R Starter Note: For Heavy Duty			

**5700-8301**

2.7kw, 12V, G/R Starter
Dim: 81mm OD x 75.5mm L



**5700-8302**

12V G/R Starter
Dim: 82mm OD x 62.5mm L

**5700-8303**

12V G/R Starter
Dim: 89mm OD x 96mm L





6100- Armature

Denso	Denso	Hitachi	Mitsubishi
 6100-8202 1.0kw G/R Starter Dim: 118.5mm OAL	 6100-8206 2.0kw Silver Body G/R Starter Dim: 135.5mm OAL	 6100-8101 2.0kw OSGR Starter Dim: 188mm OAL	 6100-8301 2.0kw~2.2kw Starter Dim: 152mm OAL, w/Bearing
 6100-8203 1.2kw Silver Body G/R Starter Dim: 118mm OAL	 6100-8207 1.4kw G/R Starter Dim: 148mm OAL, w/Bearing	 6100-8102 2.0kw~2.5kw Starter Dim: 181mm OAL	 6100-8302 0.8kw Starter Dim: 182.5mm OAL
 6100-8204 1.2kw Silver Body G/R Starter (Short) Dim: 118mm OAL	 6100-8208 1.4kw Silver Body G/R Starter Dim: 129mm OAL, w/Bearing	 6100-8103 1.4kw Starter Dim: 168mm OAL	
 6100-8205 2.0kw Early Type G/R Starter Dim: 166.5mm OAL			

6100- Armature

Nikko			
 6100-8601 4.5kw, 24V Starter Dim: 180mm OAL			






6600- Solenoid Parts

Coil	Coil	Coil	Coil
 6600-8201 12V Denso 1.0kw,1.2kw,1.4kw,1.6kw OSGR Starter Left Side:Single Wire Right Side:Double Wire	 6600-8205 12V Denso 1.2kw,1.4kw OSGR Starter Left Side: Right Side:	 6650-8202 12V Denso 2.5kw,3.0kw OSGR Starter Left Side:Double Wire Right Side:Single Wire	 6650-8206 24V Denso 4.5kw,5.5kw OSGR Starter Left Side:Double Wire Center:Single Wire
 6600-8202 12V Denso 1.0kw,1.2kw,1.4kw,1.6kw OSGR Starter Left Side:Double Wire Right Side:Single Wire	 6600-8206 12V Denso 1.0kw,1.2kw,1.4kw,1.6kw OSGR Starter Left Side:Double Wire Right Side:Single Wire	 6650-8203 12V Denso 2.5kw OSGR Starter Left Side:Single Wire Right Side:Double Wire	 6650-8207 24V Denso 4.5kw,5.5kw OSGR Starter Left Side:Single Wire Center:Double Wire
 6600-8203 12V Denso 1.2kw,1.4kw OSGR Starter Left Side:Single Wire Right Side:Double Wire	 6600-8207 12V Denso 1.4kw,1.6kw,2.0kw OSGR Starter Left Side:Single Wire Right Side:Double Wire	 6650-8204 12V Denso 2.5kw,3.0kw OSGR Starter Left Side:Double Wire Center:Single Wire	 6650-8208 24V Denso 4.5kw,5.5kw OSGR Starter Left Side:Single Wire Right Side:Double Wire
 6600-8204 12V Denso 1.2kw,1.4kw OSGR Starter Left Side:Double Wire Right Side:Single Wire	 6650-8201 12V Denso 2.5kw,3.0kw OSGR Starter Left Side:Single Wire Center:Double Wire	 6650-8205 12V Denso 2.5kw,3.0kw OSGR Starter Center:Double Wire Right Side:Double Wire	 6650-8209 24V Denso 4.5kw,5.5kw OSGR Starter Left Side:Double Wire Right Side:Single Wire



6600- Solenoid Parts

Coil	Insulator	Insulator	Insulator
 6650-8210 24V Denso 4.5kw, 5.5kw OSGR Starter Center: Single Wire Right Side: Double Wire	 6601-8201 Dim: Thickness 1.6mm	 6601-8205 Dim: Thickness 1.8mm	 6601-8209 Dim: Thickness 2.0mm
 6650-8211 12V Denso 2.5kw, 3.0kw OSGR Starter Center: Double Wire Right Side: Single Wire	 6601-8202 Dim: Thickness 1.24mm	 6601-8206 Dim: Thickness 1.4mm	 6601-8210 Dim: Thickness 1.2mm
	 6601-8203 Dim: Thickness 1.24mm	 6601-8207 Dim: Thickness 2.0mm	 6601-8211 Dim: Thickness 1.2mm
	 6601-8204 Dim: 22.9mm ID x 1.22mm Thickness	 6601-8208 Dim: Thickness 1.2mm	 6601-8212 Dim: Thickness 2.1mm


6600- Solenoid Parts

Insulator	Insulator-Paper	Insulator-Paper	Plunger
 6631-8201 Note: For Heavy Duty	 6602-8201 Dim: 11mm ID	 6602-8205 Dim:	 6603-8201 For 1.0kw,1.2kw,1.4kw,1.8kw, 2.0kw G/R Starter Dim: 36.8mm OD x 95.5mm OAL
 6631-8202 Dim: Thickness 1.4mm	 6602-8202 Dim: 13mm ID	 6602-8206	 6603-8202 For 1.0kw,1.4kw G/R Starter Dim: 36.8mm OD x 123mm OAL
 6631-8203 Dim: Thickness 1.8mm	 6602-8203 Dim: 14mm ID		 6603-8203 For 1.0kw,1.2kw,1.4kw,2.0kw G/R Starter Dim: 34.8mm OD x 96.7mm OAL
	 6602-8204 Dim: 11mm ID		 6603-8204 For 1.2kw,1.4kw G/R Starter Dim: 34.8mm OD x 125.3mm OAL



6600- Solenoid Parts

Plunger	Bobbin	Rubber Parts	Rubber Parts
 6603-8205 Dim: 36.8mm OD x 96.7mm OAL	 6604-8201 Note: For 1.2kw, 1.4kw Silver Body G/R Starter	 6605-8202 Dim: 27mm ID x 38mm OD x 2.5mm TK	 6609-8201 Note: For Heavy Duty
 6603-8206 Dim: 36.8mm OD x 135.4mm OAL	 6604-8202 Note: For 1.0kw G/R Starter	 6605-8203 For Denso 1.0kw, 1.2kw, 1.4kw, 1.6kw, 2.0 Early OSGR Starter	 5353-8201 Note: For Heavy Duty
 6603-8207 Dim: 34.8mm OD x 91.7mm OAL	 6604-8203 Note: For 1.2kw, 1.4kw Silver Body G/R Starter	 6605-8204 For Denso 1.2kw, 1.4kw OSGR Starter	
 6630-8201 Dim: 39.8mm OD x 119mm OAL	 6651-8201 Note: For 2.5kw, 3.0kw, 4.5kw, 5.5kw G/R Starter	 6651-8201	6605-8205

6600- Solenoid Parts

End Cover	End Cover	Miscellaneous	Miscellaneous
 6606-8201 For Denso 1.4kw Early Type G/R Starter	 6606-8205 For Denso G/R Starter	 6607-8201 Dim: 4mm Hole	 6607-8205 Sleeve - Coil Dim: 41.5mm L
 6606-8202 For Denso 1.4kw G/R Starter	 5352-8201 Note: For Denso Heavy Duty G/R Starter	 6607-8202 Movable Contact For 6603-8201, 6603-8202, 6603-8205, 6603-8206 Plunger	 6607-8206 Steel Support - Coil For: 1.2kw, 1.4kw Silver Body G/R Starter
 6606-8203 For Denso 1.2kw, 1.4kw Silver Body G/R Starter		 6607-8203 Movable Contact For 6603-8203, 6603-8204, 6603-8207 Plunger	 6607-8207 Back Plate - Coil For: 1.2kw, 1.4kw Silver Body G/R Starter Dim: 17.5mm ID x 34.8mm OD x 2.0mm TK
 6606-8204 For Denso 2.0kw Silver Body G/R Starter		 6607-8204 Sleeve - Coil Dim: 21.6mm ID x 36mm L	 6607-8208 Wire Clamp Dim: 4.2mm ID For: Denso 1.2kw, 1.4kw Silver Body G/R Starter


6600- Solenoid Parts

Miscellaneous	Miscellaneous	Miscellaneous	Miscellaneous
 6607-8209 Repair Retainer - Plunger Dim: 3mm Hole	 6608-8201 Holder - Plunger	 6632-8202 Spring - Plunger Dim: 5.3mm ID x 7.3mm OD x 72.5mm L	 6656-8201 Steel Support - Coil For: 2.5kw, 3.0kw, 4.5kw, 5.5kw G/R Starter
 6607-8210 Back Plate - Sol. Switch For: 1.0kw, 1.4kw G/R Starter	 6622-8201 Repair Kit Dim: w/3mm Hole	 6652-8201 Dim: 17.65mm ID x 40mm OD x 2.5mm TK	 6656-8202 Back Plate - Sol. Switch For: 2.5kw, 3.0kw, 4.5kw, 5.5kw G/R Starter
 6607-8211 Wire Clamp Dim: 5.0mm ID For: Denso 1.0kw, 1.4kw G/R Starter	 6622-8202 Repair Kit Dim: w/5mm Hole	 6652-8202 Repair Retainer - Plunger Dim: 5.0mm Hole	
	 6632-8201 Sleeve - Coil Dim: 20.7mm ID x 22mm OD x 41mm L	 6652-8204 Dim: 3/16 x 19/32 L	



6600- Solenoid Parts

Contact	Contact	Contact	Contact
 6620-8201 Battery Terminal Dim:	 6620-8205 Battery, Motor Terminal Dim: 8mm Hole	 6620-8209 Battery Terminal Dim: 8mm Hole	 6620-8213 Battery Terminal Dim: 8mm Hole Note: w/Silver Contact
 6620-8202 Battery Terminal Dim:	 6620-8206 Battery Terminal Dim: 8mm Hole	 6620-8210 Battery Terminal Dim: 10mm Hole	 6620-8214 Battery Terminal Dim: 8mm Hole
 6620-8203 Battery Terminal Dim:	 6620-8207 Battery Terminal Dim: 8mm Hole	 6620-8211 Battery Terminal Dim: 10mm Hole	 6620-8215 Battery Terminal Dim: 8mm Hole
 6620-8204 Battery Terminal Dim:	 6620-8208 Battery, Motor Terminal Dim: 8mm Hole	 6620-8212 Battery Terminal Dim: 8mm Hole	 6653-8201 Battery, Motor Terminal Dim: 10mm Hole








6600- Solenoid Parts

Contact	Contact	Contact Kit	Contact Kit
 6653-8202 Battery Terminal Dim: 8mm Hole	 6653-8206 Battery Terminal Dim: 10mm Hole	 6621-8201 Component: 6620-8205 x 2	 6621-8205 Component: 6620-8205 x 1 6620-8208 x 1
 6653-8203 Battery Terminal Dim: 10mm Hole Note: w/Silver Contact	 6653-8207 Battery Terminal Dim: 12mm Hole	 6621-8202 Component: 6620-8205 x 1 6620-8206 x 1	 6621-8206 Component: 6620-8208 x 2
 6653-8204 Battery Terminal Dim: 10mm Hole		 6621-8203 Component: 6620-8205 x 1 6620-8209 x 1	 6654-8201 Component: 6653-8201 x 1 6653-8202 x 1
 6653-8205 Battery, Motor Terminal Dim: 12mm Hole		 6621-8204 Component: 6620-8205 x 1 6620-8207 x 1	 6654-8202 Component: 6653-8201 x 2






6600- Solenoid Parts

Contact Kit	Contact Kit	Contact Kit	Terminal Post
 6654-8203 Component: 6653-8202 x 1 6653-8204 x 1	 6654-8207 Component: 6653-8201 x 1 6655-8209 x 1 7151-8201 x 1 7251-8201 x 1 7521-8203 x 1 8551-8201 x 1 8551-8202 x 1 8551-8203 x 1	 6654-8210 Component: 6653-8202 x 1 6655-8208 x 1 7151-8201 x 1 7251-8201 x 1 7251-8203 x 1 7653-8201 x 1 8551-8201 x 1 8551-8202 x 1 8551-8203 x 1	 6623-8201 Battery Dim: M8 x 1.25 x 26.8mm L
 6654-8204 Component: 6653-8204 x 2	 6654-8208 Component: 6653-8204 x 1 6655-8208 x 1 7151-8201 x 1 7251-8201 x 1 7251-8203 x 1 7653-8201 x 1 8551-8201 x 1 8551-8202 x 1 8551-8203 x 1		 6623-8202 Battery Dim: M8 x 1.25 x 30.5mm L
 6654-8205 Component: 6653-8202 x 1 6653-8204 x 1 7251-8201 x 1	 6654-8209 Component: 6653-8204 x 1 6655-8208 x 1 7151-8201 x 1 7251-8202 x 1 7251-8203 x 1 7653-8201 x 1 8551-8201 x 1 8551-8202 x 1 8551-8203 x 1 8551-8208 x 1		 6623-8203 Battery Dim: M8 x 1.25 x 30.2mm L
 6654-8206 Component: 6653-8204 x 2 7251-8201 x 1			 6623-8204 Battery Dim: M8 x 1.25 x 26.7mm L



6600- Solenoid Parts





Terminal Post	Terminal Post	Terminal Post	Terminal Post
 6623-8205 Motor Dim: M8 x 1.25 x 23.5mm L	 6655-8201 Battery Dim: M10 x 1.5 x 40mm L	 6655-8205 Battery Dim: 3/8 x 16UNC x 33mm L	 6655-8209 Motor Dim: M10 x 1.5 x 30mm L
 6623-8206 Motor Dim: M8 x 1.25 x 23.2mm L	 6655-8202 Motor Dim: M10 x 1.5 x 30mm L	 6655-8206 Battery Dim: M10 x 1.5 x 35mm L	 6655-8210 Dim: M12 x 1.75 x 50.5mm L
 6623-8207 Battery Dim: M8 x 1.25 x 33.5mm L	 6655-8203 Battery Dim: M10 x 1.5 x 44.5mm L	 6655-8207 Battery Dim: 3/8 x 16UNC x 35mm L	
 6623-8208 Battery Dim: M8 x 1.25 x 37mm L	 6655-8204 Battery Dim: M12 x 1.75 x 48.6mm L	 6655-8208 Battery Dim: M10 x 1.5 x 41mm L	

6900- Brush Holder Assembly


Denso	Denso	Denso	Hitachi
 6900-8201 2.0kw, CW Golden Case G/R Starter OEM: 028000-644, 128000-002, 288 Lester: 16739	 6900-8205 1.0kw, CW Late Type G/R Starter OEM: 028000-424, 822, 128000-442 Lester: 16248, 16828, 17171	 6900-8210 1.2kw, CCW Silver Body G/R Starter OEM: 228000-567, 568, 627 Lester: 17715, 17716, 17777	 6900-8101 1.8kw, 2.0kw, CW OSCR Starter OEM: S13-47, 62, 65 Lester: 16733, 16740, 16772
 6900-8202 1.0kw, 1.4kw, CW Golden Case G/R Starter OEM: 028000-360, 454, 662, 823 Lester: 16236, 16248, 16251, 17100	 6900-8206 1.4kw, CCW Golden Case G/R Starter OEM: 028000-655 Lester: 16696	 6900-8212 1.4kw, CCW G/R Starter OEM: 028000-980, 128000-720, 840 Lester: 17263, 17400, 17774	
 6900-8203 1.4kw, CW Silver Body G/R Starter OEM: 228000-257, 374 Lester: 17668	 6900-8208 2.0kw Silver Body G/R Starter OEM: 228000-304, 326, 430 Lester: 17533, 17535, 17581		
 6900-8204 0.8kw, CCW DD Starter OEM: 028000-216, 222, 652 Lester: 16468, 16804	 6900-8209 1.2kw, CW Silver Body G/R Starter OEM: 228000-090, 115, 301, Lester: 17487, 17531, 17571		

6900- Brush Holder Assembly


Mitsubishi			
 6900-8301 2.2kw, CW OSGR Starter CEM: M2T54371, M2T60071 Lester: 16744, 16799			
 6900-8302 1.4kw, 1.7kw, CW PMGR Starter CEM: M1T71681, M1T73581 Lester: 16874, 17046			
 6900-8303 2.2kw, CW OSGR Starter CEM: M1T74281, M1T76081 Lester: 17006, 17467			

O-Ring	O-Ring	O-Ring	O-Ring
 7101-8201 Dim:4mm ID x 8mm OD x 2mm TK Note:For Screw-Brush Holder	 7101-8211 Dim:69.5mm ID x 73.5mm OD x 2mm TK Note:For 1.0kw,1.2kw,1.4kw,2.0kw Field Case	 7101-8215 Dim:3.7mm ID x 7.7mm OD x 2mm TK Note:For Brush Holder Screw	 7101-8219 Dim:1.5mm TK Note:For 2.0kw Early Type OSGR Starter
 7101-8203 Dim:5mm ID x 9mm OD x 2mm TK Note:For Terminal,Through Bolt	 7101-8212 Dim:69.5mm ID x 73.5mm OD x 2mm TK(Square) Note:For 1.0kw,1.4kw,1.8kw Field Case	 7101-8216 Dim:17.2mm ID x 1.2mm TK	 7101-8220 Note:Used on Mitsuba Drive End Frame
 7101-8205 Dim:7.6mm ID x 11.2mm OD x 1.8mm TK Note:For Battery,Motor Terminal	 7101-8213 Dim:71.3mm ID x 74.3mm OD x 1.5mm TK Note:For 1.0kw,1.2kw,1.4kw,2.0kw Field Case	 7101-8217 Dim:8mm ID x 2mm TK Note:For Terminal Post	 7101-8221 Note:Used on Mitsuba Switch Cap
 7101-8209 Dim:42.5mm ID x 47.7mm OD Note:For 1.0kw,1.2kw,1.4kw Field Case	 7101-8214 Dim:7.9mm ID x 1.9mm TK Note:For Terminal Post	 7101-8218 Dim:6mm ID x 9.6mm OD x 1.8mm TK Note:For Terminal Post, Through Bolt	 7151-8201 Dim:10mm ID x 2mm TK Note:For Heavy Duty Battery Terminal

7101 ~ 7151 Rubber Parts

O-Ring	Boot	Boot	Boot
 7151-8202 Note:For 2.5kw,3.0kw,4.5kw,5.5kw Field Case Dim:95.0mm ID x 99.0mm OD x 2.0mm TK	 7102-8201 For Denso 1.0kw,1.2kw,1.4kw Note:Blue Color	 7102-8205 Dim:7mm Hole	 7102-8209
 7151-8203 Note:For 2.5kw,3.0kw,4.5kw,5.5kw D.E Frame Dim:48mm ID x 53mm OD x 2.5mm TK	 7102-8202 For Denso 1.0kw,1.2kw,1.4kw Note:Gray Color	 7102-8206 For Denso 1.0kw,1.2kw	 7102-8210 For Denso 1.0kw,1.2kw,1.4kw Note:Ivory Color
 7151-8204 Note:For Denso Heavy Duty Dim:	 7102-8203 For Denso 1.0kw,1.2kw,1.4kw Note:Blue Color	 7102-8207 For Denso 1.0kw,1.2kw	 7102-8211 For Denso 1.0kw,1.2kw,1.4kw Note:Black Color
	 7102-8204 For Denso 1.6kw,2.0kw	 7102-8208 For Mitsuba SM-302-07	 7102-8212 For Denso 1.0kw,1.2kw,1.4kw Note:Black Color



7101 ~ 7151 Rubber Parts



Boot	Grommet	Grommet	Grommet
 7102-8213 Dim:4mm Hole	 7103-8201 For Denso 1.4kw,2.0kw Note:Blue Color	 7103-8205 Dim:10mm ID x 80mm L Note:Blue Color	 7103-8209
 7102-8214 For Denso 1.0kw,1.2kw,1.4kw	 7103-8202 For Denso 1.0kw	 7103-8206 For Hitachi	 7103-8210
 7151-8207 Note:For Denso 2.5kw,3.0kw,4.5kw,5.5kw	 7103-8203 Dim:7mm ID x 81.5mm L	 7103-8207	 7103-8211
	 7103-8204 For Denso 1.2kw,1.4kw Note:Blue Color	 7103-8208 Dim:4mm Hole	 7103-8212

7101 ~ 7151 Rubber Parts




Grommet	Drain Tube	Drain Tube	Drain Tube
 7151-8208 Note:For Denso Heavy Duty	 7104-8201 Dim:6mm Hole	 7104-8205 Dim:8mm Hole	 7151-8206 For Denso 2.5kw Dim:12mm Hole
	 7104-8202 Dim:12mm Hole	 7104-8206	
	 7104-8203 Dim:12mm Hole	 7104-8207	
	 7104-8204 Dim:6mm Hole	 7104-8208 Note:For Denso 428000-093	



7101 ~ 7151 Rubber Parts

Plug	Plug	Plug	
 7105-8201 For Denso 1.0kw	 7105-8205 For Hitachi Shift Lever	 7105-8209 For Hitachi Field Housing	
 7105-8202	 7105-8206 For Hitachi Shift Lever	 7105-8210 Dim:9mm	
 7105-8203 For Mitsubishi Shift Lever	 7105-8207 For Mitsubishi Shift Lever	 7105-8211 For Hitachi Field Housing	
 7105-8204 For Hitachi Shift Lever	 7105-8208 Dim:11.5mm		



For Terminal	For Terminal	For Terminal	For Terminal
 7201-8201 Dim:11.5mm ID	 7201-8206 Dim:11.5mm ID	 7251-8203 Dim:10mm ID Note:For Denso Heavy Duty G/R Starter	 7251-8207 Dim:10mm ID Note:For Denso Heavy Duty G/R Starter
 7201-8202 Dim:8mm ID	 7201-8207	 7251-8204 Dim:16mm ID x 10mm L Note:For Denso Heavy Duty G/R Starter	 7251-8208 OEM:428000-1190 Lester:17892 Dim:16mm ID x 10mm L Note:For Denso Heavy Duty G/R Starter
 7201-8204 Dim:8mm ID	 7251-8201 Dim:13.6mm ID Note:For Denso Heavy Duty G/R Starter	 7251-8205 Dim:13mm ID Note:For Denso Heavy Duty G/R Starter	
 7201-8205 Note:For Denso 1.0kw,1.2kw,1.4kw,1.6kw,1.8kw,2.0kw Starter	 7251-8202 Dim:13.5mm ID Note:For Denso Heavy Duty G/R Starter	 7251-8206 Dim:11.5mm ID Note:For Denso Heavy Duty G/R Starter	

7201 ~ 7251 Insulator

Cover	Cover	Cover	For Field Coil
 7202-8201 Note:For Denso 1.4kw Starter	 7202-8205 Note:For Denso 1.0kw,1.2kw Starter	 7202-8209 Dim:44mm OD	 7203-8201 Note:For Denso 1.4kw Starter
 7202-8202 Note:For Denso G/R Starter	 7202-8206 Note:For Denso G/R Starter	 7202-8210 Dim:48mm OD	 7203-8202 Note:For Denso G/R Starter
 7202-8203 Note:For Denso G/R Starter	 7202-8208 Note:For Denso G/R Starter	 7202-8211	
 7202-8204 Note:For Denso 1.4kw Starter			

Terminal Switch	Terminal Switch	Terminal Switch	Terminal Switch
 7601-8201 Note:For Denso 1.0kw,1.2kw,1.4kw Dim:M4 x 0.7	 7601-8205 Note:For Denso 1.2kw,1.4kw	 7601-8209 Dim:M4 x 0.7	 7601-8213 Note:For Denso G/R Starter
 7601-8202 Note:For Denso 1.0kw,1.2kw,1.4kw,1.6kw	 7601-8206 Note:For Denso 1.0kw,1.2kw,1.4kw,1.6kw 1.8kw,2.0kw	 7601-8210 Dim:M5 x 0.8	 7601-8214 Note:For Denso 1.2kw,1.4kw,1.8kw
 7601-8203 Note:For Denso 1.4kw Dim:M4 x 0.7	 7601-8207 Note:For Denso 1.4kw Dim:M5 x 0.8	 7601-8211 Note:For Denso 1.2kw,1.4kw Dim:M5 x 0.8	 7601-8215 Note:For Denso 1.0kw,1.4kw Dim:M4 x 0.7
 7601-8204 Note:For Denso 1.2kw,1.4kw	 7601-8208 Note:For Denso 1.2kw,1.4kw	 7601-8212 Note:For Denso 1.2kw,1.4kw Dim:M5 x 0.8	 7601-8216 Note:For Denso 1.0kw,1.2kw,1.4kw,2.0kw Dim:M4 x 0.7

7601- ~ 7653- Miscellaneous

Terminal Switch	Terminal Switch		Roller Retainer
 7601-8217 Note:For Denso G/R Starter	 7651-8202 Note:For Denso 2.5kw,4.5kw,3.0kw,5.5kw Dim:M4 x 0.7	 7651-8206 OEM:428000-1190 Lester:17892 Dim:16mm ID x 10mm L Note:For Denso Heavy Duty G/R Starter	 7602-8201 Note:For 1.0kw,1.2kw1.4kw,1.6kw,1.8kw 2.0kw,2.2kw Dim:21mm OD x 13.2mm L
 7601-8219 Note:For Denso G/R Starter	 7651-8203 Note:For Denso 2.5kw,4.5kw,3.0kw,5.5kw Dim:M5 x 0.8		 7602-8202 Note:For 1.2kw1.4kw,1.8kw,2.0kw Dim:21mm OD x 11.3mm L
 7601-8220 Note:For Denso G/R Starter	 7651-8204 Note:For 1.0kw,1.2kw1.4kw,1.6kw, 2.0kw Dim:21mm OD x 13.2mm L		 7652-8201 Note:For 2.5kw,3.0kw,4.5kw,5.5kw Dim:28.7mm OD x 16.5mm L
 7651-8201 Note:For Denso 3.0kw Dim:M5 x 0.8	 7651-8205 Note:For Denso 3.0kw,4.5kw		



7601- ~ 7653- Miscellaneous

Retaining Ring	Retaining Ring	Stop Collar	Stop Collar
 7605-8201 Note: For 1.0kw, 1.2kw, 1.4kw, 1.6kw, 2.0kw Dim: 1.6mm Wire Dia.	 7653-8204 Note: For Denso G/R Starter Dim: 8.7mm ID x 11.9mm OD x 1.6mm TK	 7606-8201 Note: For 1.0kw, 1.2kw, 1.4kw, 1.6kw, 2.0kw Dim: 13mm ID x 18mm OD x 4.6mm W	 7653-8205 Note: For 2.5kw, 3.0kw, 4.5kw, 5.5kw Dim: 11mm ID x 20mm OD x 5.5mm W
 7605-8202 Dim: 16.4mm OD x 1.5mm TK		 7606-8202 Note: For 1.0kw, 1.2kw, 1.4kw, 1.6kw, 2.0kw Dim: 21mm ID x 41.2mm OD x 3.5mm H	
 7605-8204 Note: For Mitsuba Starter Dim: 9mm OD x 1.9mm Wire Dia.		 7606-8203 Note: For Denso G/R Starter Dim:	
 7605-8251 Note: For 2.5kw, 3.0kw, 4.5kw, 5.5kw Dim:		 7606-8204 Note: For G/R Starter Dim: 17.6mm ID x 19.5mm OD	



7601- ~ 7653- Miscellaneous

Roller Pin	Roller Pin	Heat Shield	B+ Terminal Extension
 7608-8201 Note:For 1.0kw,1.2kw1.4kw,1.6kw,1.8kw 2.0kw,2.2kw Dim:6mm OD x 9.5mm L	 7653-8202 Note:For 1.0kw G/R Starter Dim:7.6mm OD x 13mm L	 7610-8201 For 128000-527	 7611-8202 For Denso Silver Body G/R Starter Dim:M8 x 1.25
 7608-8203 Dim:7mm OD x18.35mm L		 7610-8202 For 128000-527	 7611-8203 For Denso 1.4kw Dim:M8 x 1.25
 7608-8207 Note:For 1.2kw,1.4kw,1.8kw,2.0kw Dim:7.4mm OD x 13mm L		 7610-8203 For 128000-257,128000-258	 7612-8201 For Denso 1.0kw,1.2kw Dim:M4 x 0.7
 7608-8208 Note:For 1.2kw,1.4kw,1.8kw,2.0kw Dim:6mm OD x 9.5mm L			 7612-8202 For Denso 1.4kw Dim:M5 x 0.8

7601- ~ 7653- Miscellaneous

B+ Terminal Extension	B+ Terminal Extension	Connector	Connector
 7612-8203 For Denso 1.4kw Dim:M4 x 0.7	 7612-8207 For Denso G/R Starter	 7613-8201 For Denso Field Coil	 7614-8201 For Denso Silver Body G/R Starter
 7612-8204 Dim:M8 x 1.25	 7612-8208 Dim:M5 x 0.8	 7613-8202 For Denso Field Coil	 7614-8202 For Denso Silver Body G/R Starter
 7612-8205 Dim:M8 x 1.25		 7613-8203 For Denso 1.0kw,1.4kw Field Coil	 7614-8203 For Denso 2.0kw G/R Starter
 7612-8206 For Denso G/R Starter		 7613-8204 For Denso G/R Starter Field Coil Dim:8.5mm ID	 7614-8204 For Denso 1.4kw G/R Starter


7601- ~ 7653- Miscellaneous

Connector	Bracket	Bracket	Bracket
 7614-8205 For Denso 1.4kw G/R Starter	 7613-8205 For Denso G/R Starter	 7613-8211 For Denso 1.2kw G/R Starter	 7613-8215 For Mitsuba SM302-44
 7653-8201 For Denso G/R Starter	 7613-8206 For Denso G/R Starter	 7613-8212 For Mitsuba SM402-05	 7613-8216 For 128000-975,228000-206 G/R Starter
 7653-8203 For Denso G/R Starter	 7613-8207 For Denso G/R Starter	 7613-8213 For Mitsuba SM402-03	 7613-8217 For Denso G/R Starter
	 7613-8208 For Denso 1.2kw,1.4kw G/R Starter	 7613-8214 For Mitsuba Starter	 7613-8218 For 228000-646 PLGR Starter

7601- ~ 7653- Miscellaneous

Others	Others		
 7617-8201 Plug-Expansion	 7620-8202 Note:For 1.0kw Clutch Barrel		
 7617-8202 For 2.0kw	 7621-8201 Note:For Hitachi Solenoid Switch		
 7618-8201 Solenoid Strap Dim:	 7653-8206 Note:For 2.5kw,3.0kw,4.5kw,5.5kw Dim:15mm ID x 40mm OD		
 7620-8201 For 1.0kw Clutch Barrel			


7601- ~ 7653- Miscellaneous

Shield	Terminal Block	Connector Wire	Steel Ball
 7613-8209 For 228000-041,228000-071	 7616-8201 For Denso G/R Starter Dim:M4 x 0.7, M8 x 1.25	 7619-8201 For 1.2kw,1.4kw G/R Starter	 7608-8204 Note:For 1.0kw,1.2kw,1.4kw,1.6kw,1.8kw 2.0kw,2.2kw,2.5kw,3.0kw,4.5kw,5.5kw Dim:8.7mm
 7613-8210 For 128000-700,128000-878	 7616-8202 For Denso G/R Starter Dim:M5 x 0.8, M8 x 1.25	 7619-8202 For Hitachi,Mitsubishi Starter	
	 7616-8203 For 228000-504	 7619-8203 For 428000-0931	
		 7659-8201 For Denso Heavy Duty G/R Starter	

8400- ~ 8451- Screw And Bolt

Drive End Frame	Drive End Frame	Drive End Frame	Through Bolt
 8400-8201 Dim:M6 x 1.0 x 50mm L	 8400-8205 Dim:M5 x 0.8 x 36mm L	 8400-8210 Dim:M6 x 1.0 x 42.5mm L	 8401-8201 Dim:M6 x 1.0 x 139mm L
 8400-8202 Dim:M6 x 1.0 x 40mm L	 8400-8206 Dim:M5 x 0.8 x 35mm L	 8400-8211 Dim:M6 x 1.0 x 30mm L	 8401-8202 Dim:M6 x 1.0 x 150mm L
 8400-8203 Dim:M6 x 1.0 x 50mm L	 8400-8207 Dim:M6 x 1.0 x 60mm L	 8451-8203 Dim:M6 x 1.0 x 49mm L Note:For Denso Heavy Duty G/R Starter	 8401-8203 Dim:M6 x 1.0 x 138mm L
 8400-8204 Dim:M6 x 1.0 x 40mm L	 8400-8208 Dim:M6 x 1.0 x 40mm L		 8401-8204 Dim:M6 x 1.0 x 139mm L



8400- ~ 8451- Screw And Bolt

Through Bolt	Through Bolt	Commutator End Frame	Commutator End Frame
 8401-8205 Dim:M5 x 0.8 x 115mm L	 8401-8209 Dim:M5 x 0.8 x 127mm L	 8402-8201 Dim:M4 x 0.7 x 10mm L	 8402-8205 Dim:M5 x 0.8 x 9.5mm L
 8401-8206 Dim:M6 x 1.0 x 166mm L	 8401-8210 Dim:M6 x 1.0 x 76.5mm L	 8402-8202 Dim:M4 x 0.7 x 11mm L	 8402-8206 Dim:M4 x 0.7 x 13.5mm L
 8401-8207 Dim:M6 x 1.0 x 88mm L	 8451-8204 Dim:M6 x 1.0 x 182mm L Note:For Denso Heavy Duty G/R Starter	 8402-8203 Dim:M4 x 0.7 x 6mm L	 8451-8205 Dim:M5 x 0.8 x 12.4mm L Note:For Denso Heavy Duty G/R Starter
 8401-8208 Dim:M6 x 1.0 x 76.4mm L		 8402-8204 Dim:M5 x 0.8 x 6mm L	 8451-8206 Dim:M5 x 0.8 x 13mm L Note:For Denso Heavy Duty G/R Starter

8400- ~ 8451- Screw And Bolt

End Cover	End Cover	Field Case	Field Case
 8403-8201 Dim:M6 x 1.0 x 36mm L	 8403-8205 Dim:M4 x 0.7 x 12mm L	 8404-8201 Dim:M8 x 1.25 x 12mm L	 8451-8207 Dim:M10 x 1.5 x 11.5mm L Note:For Denso Heavy Duty G/R Starter
 8403-8202 Dim:M5 x 0.8 x 22mm L	 8403-8206 Dim:M4 x 0.7 x 12mm L	 8404-8202 Dim:M8 x 1.25 x 29mm OAL	
 8403-8203 Dim:M5 x 0.8 x 14mm L	 8403-8207 Dim:M4 x 0.7 x 21.9mm L	 8404-8203 Dim:M10 x 1.5 x 11.4mm L	
 8403-8204 Dim:M4 x 0.7 x 16mm L		 8451-8202 Dim:M10 x 1.5 x 12mm L Note:For Denso Heavy Duty G/R Starter	


TACTCAST

Hex Nut	Hex Nut	Hex Nut	Hex Nut
 8501-8207 Dim:M8 x 1.25 x 6.4mm Thickness	 8501-8211 Dim:M5 x 0.8 x 4mm Thickness	 8501-8215 Dim:M4 x 0.7 x 3.5mm Thickness	 8501-8219 Dim:M6 x 1.0 x 5.85mm Thickness
 8501-8208 Dim:M8 x 1.25 x 4mm Thickness	 8501-8212 Dim:M12 x 8mm Thickness	 8501-8216 Dim:M16 x 1.0 x 8mm Thickness	 8501-8220 Dim:M10 x 1.0 x 8mm Thickness
 8501-8209 Dim:M6 x 1.0 x 5mm Thickness	 8501-8213 Dim:M8 x 1.25 x 4mm Thickness	 8501-8217 Dim:M8 x 1.25 x 1.5mm Thickness	 8501-8221 Dim:M8 x 1.25 x 3.1mm Thickness
 8501-8210 Dim:M8 x 1.25 x 4mm Thickness	 8501-8214 Dim:M16 x 1.5 x 13mm Thickness	 8501-8218 Dim:M12 x 1.5 x 7mm Thickness	 8501-8222 Dim:M14 x 1.5 x 8mm Thickness

8501- ~ 8551- Nut And Washer

Hex Nut	Hex Nut	Split Lock Washer	Split Lock Washer
 8551-8201 Dim:M10 x 1.5 x 6mm Thickness	 8551-8208 Dim:M10 x 1.5 x 12mm Thickness Note:For 2.5kw (Steel)	 8502-8208 Dim:M4 x 1.3mm Thickness	 8502-8212 Dim:M14 x 3.5mm Thickness
 8551-8204 Dim:3/8 - 16UNC x 12mm Thickness Note:For 2.5kw	 8551-8209 Dim:M10 x 1.5 x 12mm Thickness Note:For 2.5kw (Brass)	 8502-8209 Dim:M8 x 2.38mm Thickness	 8551-8203 Dim:10.4mm ID x 16.5mm OD x 2mm Thickness
 8551-8205 Dim:3/8 - 16UNC x 12mm Thickness Note:For 2.5kw (Brass)	 8551-8212 Dim:M12 x 1.75 x 12mm Thickness Note:Brass	 8502-8210 Dim:M5 x 1.4mm Thickness	 8551-8214 Dim:12.6mm ID x 20.8mm OD x 2.96mm Thickness Note:For 2.5kw (Steel)
 8551-8206 Dim:3/8 - 16UNC x 6mm Thickness Note:Brass	 8551-8213 Dim:M12 x 1.75 x 7mm Thickness	 8502-8211 Dim:M6 x 1.96mm Thickness	

8501- ~ 8551- Nut And Washer

Curve Washer	Flat Washer		
 8503-8202 Dim:8.26mm ID x 16.1mm OD x 1mm Thickness Note:For 3.0kw	 8551-8210 Dim:6.2mm ID x 14.85mm OD x 2.7mm Thickness		
 8551-8202 Dim:10.4mm ID x 20mm OD x 1mm Thickness	 8551-8211 Dim:12.6mm ID x 20.8mm OD x 2.7mm Thickness		
 8551-8207 Dim:12.4mm ID x 22mm OD x 1mm Thickness Note:For 3.0kw			

5MT ~ SD300

Aluminum



5100-100

For Delco 5MT, SD200 Series DD Starter

Lester:3535,3571,6307,6310

Aluminum



5100-110

For Delco SD260 Series DD Starter

Lester:6416

Wet Clutch
Cast Iron



5100-114

For Delco 10MT, 20MT, 22MT, SD300 Series DD Starter

Lester:

Cast Iron



5100-124

For Delco 10MT, SD300 Series DD Starter

Lester:

Aluminum



5100-101

For Delco 5MT, SD200 Series DD Starter

Lester:3552,6327

Cast Iron



5100-111

For Delco 10MT, SD300 Series DD Starter

Lester:3686

Wet Clutch
Cast Iron



5100-115

For Delco 10MT, 20MT, 22MT, SD300 Series DD Starter

Lester:

Wet Clutch
Cast Iron



5100-126

For Delco 10MT, 20MT, SD300 Series DD Starter

Lester:

Aluminum



5100-102

For Delco 5MT, SD200 Series DD Starter

Lester:3553,6316

Cast Iron



5100-112

For Delco 10MT, 20MT, 22MT, 25MT, 27MT Series DD Starter

Lester:4237,4249,4383,4393,6178

Cast Iron



5100-116

For Delco 10MT, 20MT, 22MT, 25MT, 27MT, SD300 Series DD Starter

Lester:

Cast Iron



5100-128

For Delco 10MT, SD300 Series DD Starter

Lester:3554,3556,3560,3672,3649,3689

Aluminum



5100-105

For Delco SD210 Series DD Starter

Lester:6415

Cast Iron



5100-113

For Delco 10MT, SD300 Series DD Starter

Lester:4545

Cast Iron



5100-119

For Delco 10MT, SD300 Series DD Starter

Lester:6303,6304

Cast Iron



5100-129

For Delco 10MT Series DD Starter

Lester:3629

5MT ~ SD300



Cast Iron

5100-130

For Delco 10MT, SD300 Series DD Starter

Lester:3633




Cast Iron

5100-136

For Delco 10MT, SD300 Series DD Starter

Lester:3533,4208




Ductile Iron

5100-145

For Delco 30MT, 35MT Series External Rotatable DD Starter

Lester:



Ductile Iron

5100-163

For Delco 37MT Series DD Starter

Lester:




Cast Iron

5100-131

For Delco 10MT, SD300 Series DD Starter

Lester:3551,4174




Wet Clutch
Cast Iron

5100-137

For Delco 10MT, 22MT, SD300 Series DD Starter

Lester:




Cast Iron

5100-154

For Delco 30MT, 35MT Series Internal Rotatable DD Starter

Lester:



Cast Iron

5100-164

For Delco 37MT Series DD Starter

Lester:



Cast Iron

5100-134

For Delco 10MT, 20MT, 22MT, 25MT, 27MT Series DD Starter

Lester:



Ductile Iron

5100-141

For Delco 30MT, 35MT External Rotatable DD Starter

Lester:




Ductile Iron

5100-159

For Delco 30MT, 35MT Series Internal Rotatable DD Starter

Lester:



Ductile Iron

5100-165

For Delco 37MT Series DD Starter

Lester:



Cast Iron

5100-135

For Delco 10MT, SD300 Series DD Starter

Lester:4083,4349,4430,6376




Cast Iron

5100-142

For Delco 20MT, 25MT Series Starter

Lester:3601




Ductile Iron

5100-161

For Delco 30MT, 35MT Series Internal Rotatable DD Starter

Lester:6416



Cast Iron

5100-167

For Delco 40MT, 50MT Series DD Starter

Lester:

5MT ~ SD300

Ductile Iron




5100-168

For Delco 40MT, 50MT Series DD Starter

Lester:

Ductile Iron



5100-178

For Delco 25MT, 27MT Series Starter

Lester:3772,6301,6305

Cast Iron



5100-194

For Delco 10MT Series DD Starter

Lester:

Ductile Iron




5100-1119

For Delco 37MT Series DD Starter

Lester:

Ductile Iron




5100-171

For Delco 42MT Series DD Starter

Lester:

Cast Iron



5100-179

For Delco 10MT, 20MT, 22MT, 25MT, 27MT, SD300 Series DD Starter

Lester:

Ductile Iron



5100-1112

For Delco 42MT Series DD Starter

Lester:

Wet Clutch
Cast Iron




5100-1120

For Delco 10MT, 20MT, 22MT, 27MT, SD300 Series DD Starter

Lester:

Ductile Iron



5100-172

For Delco 50MT Series DD Starter

Lester:

Wet Clutch
Cast Iron



5100-189

For Delco 10MT, 20MT, 22MT, 27MT, SD300 Series DD Starter

Lester:

Ductile Iron



5100-1117

For Delco 42MT Series DD Starter

Lester:

Ductile Iron



5100-1121

For Delco 10MT, 20MT, 22MT, 27MT, SD300 Series DD Starter

Lester:

Ductile Iron




5100-173

For Delco 50MT Series DD Starter

Lester:

Cast Iron



5100-190

For Delco 10MT, 20MT, 22MT, 27MT, SD300 Series DD Starter

Lester:3300

Ductile Iron



5100-1118

For Delco 37MT Series DD Starter

Lester:

Wet Clutch
Cast Iron








5100-5047


For Delco Series DD Starter





Lester:

5100- Drive End Frame




Delco

PG260	28MT	28MT	28MT
Aluminum  5100-1107 For Delco PG260 Series PMGR Starter Replaces:10476596	Aluminum  5100-8400 For Delco 28MT Series Starter Replaces:10456471	Aluminum  5100-8405 For Delco 28MT Series Starter Replaces:10457029,10457170	Aluminum  5100-5810 For Delco 28MT Series Starter Replaces:10457142
Aluminum  5100-1108 For Delco PG260 Series PMGR Starter Replaces:10476220	Aluminum  5100-8401 For Delco 28MT Series Starter Replaces:10456472	Aluminum  5100-8406 For Delco 28MT Series Starter Replaces:10457052	Aluminum  5100-5811 For Delco 28MT Series Starter Replaces:
Aluminum  5100-1109 For Delco PG260 Series PMGR Starter Replaces:10476793	Aluminum  5100-8403 For Delco 28MT Series Starter Replaces:10457030,10457180	Cast Iron  5100-8407 For Delco 28MT Series Starter Replaces:10457050	Aluminum  5100-5812 For Delco 28MT Series Starter Replaces:10457053
Aluminum  5100-1110 For Delco PG260 Series PMGR Starter Replaces:10476639	Aluminum  5100-8404 For Delco 28MT Series Starter Replaces:10457026	Aluminum  5100-8408 For Delco 28MT Series Starter Replaces:10457031	Aluminum  5100-5813 For Delco 28MT Series Starter Replaces:


28MT			
Aluminum  5100-5814 For Delco 28MT Series Starter Replaces:	Cast Iron  5100-5401 For Delco DD Series Starter Replaces:	Cast Iron  5100-5405 For Delco DD Series Starter Replaces:	Cast Iron  5100-5409 For Delco DD Series Starter Replaces:
Cast Iron  5100-5815 For Delco 28MT Series Starter Replaces:	Cast Iron  5100-5402 For Delco DD Series Starter Replaces:	Cast Iron  5100-5406 For Delco DD Series Starter Replaces:	Cast Iron  5100-5410 For Delco DD Series Starter Replaces:
	Cast Iron  5100-5403 For Delco DD Series Starter Replaces:	Cast Iron  5100-5407 For Delco DD Series Starter Replaces:1987705	Cast Iron  5100-5411 For Delco DD Series Starter Replaces:
	Cast Iron  5100-5404 For Delco DD Series Starter Replaces:	Cast Iron  5100-5408 For Delco DD Series Starter Replaces:10455328	Cast Iron  5100-5412 For Delco DD Series Starter Replaces:

Cast Iron  5100-5413 For Delco DD Series Starter Replaces:	Cast Iron  5100-5417 For Delco DD Series Starter Replaces:	Cast Iron  5100-5421 For Delco DD Series Starter Replaces:	Cast Iron  51-95132 For Delco Series Starter Replaces:
Cast Iron  5100-5414 For Delco DD Series Starter Replaces:	Cast Iron  5100-5418 For Delco DD Series Starter Replaces:	Aluminum  5100-2000A For Delco DD Series Starter OEM: FAF11001A, SA523	Cast Iron  51-95133 For Delco Series Starter Replaces:
Cast Iron  5100-5415 For Delco DD Series Starter Replaces:	Cast Iron  5100-5419 For Delco DD Series Starter Replaces: 1971343	Aluminum  5100-2000B For Delco DD Series Starter OEM: 8N11001, 9N11001, 9N11002, SA-546	Cast Iron  51-95134 For Delco Series Starter Replaces:
Cast Iron  5100-5416 For Delco DD Series Starter Replaces:	Cast Iron  5100-5420 For Delco DD Series Starter Replaces:	Aluminum  5100-2003 For Delco DD Series Starter OEM:	Cast Iron  51-95135 For Delco Series Starter Replaces:

Cast Iron  51-95136 For Delco Series Starter Replaces:	Cast Iron  51-95168 For Delco Series Starter Replaces:	Cast Iron  51-95172 For Delco Series Starter Replaces:	
Cast Iron  51-95138 For Delco Series Starter Replaces:	Cast Iron  51-95169 For Delco Series Starter Replaces:		
Ductile Iron  51-95165 For Delco Series Starter Replaces:	Cast Iron  51-95170 For Delco Series Starter Replaces:		
Ductile Iron  51-95166 For Delco Series Starter Replaces:	Cast Iron  51-95171 For Delco Series Starter Replaces:		

4" Mod II	4" Mod II	4-1/2", 4-1/2" Mod I, II	PMGR
Aluminum  5101-204 For Ford 4" Mod II Starter Lester:3185	Aluminum  5101-211 For Ford 4" Mod II Starter Lester:3180	Aluminum  5101-215 For Ford 4-1/2", 4-1/2" Mod I Starter Lester:3149,3152	Aluminum  5101-237 For Ford PMGR Starter Lester:3205,3268
Aluminum  5101-205 For Ford 4" Mod II Starter Lester:3185	Aluminum  5101-229 For Ford 4" Mod II Starter Lester:3188	Aluminum  5101-216 For Ford 4-1/2", 4-1/2" Mod I Starter Lester:3131,3155	Aluminum  5101-238 For Ford PMGR Starter Lester:3204,3270
Aluminum  5101-209 For Ford 4" Mod II Starter Lester:3175,3191	Aluminum  5101-230 For Ford 4" Mod II Starter Lester:3198	Aluminum  5101-234 For Ford 4-1/2" Mod II Starter Lester:3168	Aluminum  5101-239 For Ford PMGR Starter Lester:3213,3272
Aluminum  5101-210 For Ford 4" Mod II Starter Lester:3179M,3181M		Aluminum  5101-215 For Ford 4-1/2" Mod II Starter Lester:3174	Aluminum  5101-240 For Ford PMGR Starter Lester:3214

5101- Drive End Frame

PMGR	PMGR	PMGR	PMGR
Aluminum  5101-241 For Ford PMGR Starter Lester:3232,3240	Aluminum  5101-245 For Ford PMGR Starter Lester:3217,6645	Aluminum  5101-249 For Ford PMGR Starter Lester:3221,3267	Aluminum  5101-253 For Ford PMGR Starter Lester:3261
Aluminum  5101-242 For Ford PMGR Starter Lester:3224,3239	Aluminum  5101-246 For Ford PMGR Starter Lester:3225,3246	Aluminum  5101-250 For Ford PMGR Starter Lester:3235,6640	Aluminum  5101-254 For Ford PMGR Starter Lester:3262
Aluminum  5101-243 For Ford PMGR Starter Lester:3231,3238	Aluminum  5101-247 For Ford PMGR Starter Lester:3234	Aluminum  5101-251 For Ford PMGR Starter Lester:3226,3247	Aluminum  5101-257 For Ford PMGR Starter Lester:3269,3274
Aluminum  5101-244 For Ford PMGR Starter Lester:3242	Aluminum  5101-248 For Ford PMGR Starter Lester:3223,3241	Aluminum  5101-252 For Ford PMGR Starter Lester:3230	Aluminum  5101-258 For Ford PMGR Starter Lester:3271,3273


5MT ~ SD300



5200-100

For Delco 5MT,SD200,SD205,SD210
Series DD Starter


Lester:



5200-104

For Delco 22MT,27MT Series DD;
15GR Series OSGR Starter

Lester: 3725, 3741, 3764, 6305, 6343



5200-111

For Delco 40MT Series DD Starter

Lester:



5200-121

For Delco 10MT,20MT,25MT,SD300
Series DD Starter

Lester:



5200-101

For Delco 5MT,SD200 Series DD
Starter


Lester: 3502, 3503, 3504, 3535, 3562



5200-106

For Delco 30MT,35MT Series
External Rotatable DD Starter


Lester:



5200-114

For Delco 50MT Series DD Starter

Lester: 18197



5200-122

For Delco 25MT,27MT Series DD
Starter

Lester: 3300, 3633, 3664



5200-102

For Delco 5MT,SD200,SD205,SD210
Series DD Starter

Lester:



5200-108

For Delco 30MT,35MT Series
Internal Rotatable DD Starter

OEM: 1945617, 1966265, 1967224



5200-115

For Delco 50MT Series DD Starter

Lester:



5200-124

For Delco 37MT,41MT Series DD
Starter

Lester:



5200-103

For Delco 10MT,20MT,25MT,SD300
Series DD Starter

Lester: 18197



5200-110

For Delco 37MT Series DD Starter

Lester:



5200-117



For Delco 42MT Series DD Starter





Lester: 18197

5200- Commutator End Frame


Delco

28MT	PG260M		
 5200-8400 For 28MT Series OSGR Starter Lester: Note:	 5200-127 For Delco PG260M PMGR Starter Lester: 6449, 6470, 6479, 6482 Note: w/Drain Hole		
 5200-8401 For 28MT Series OSGR Starter Lester: Note:	 5200-128 For Delco PG260M PMGR Starter Lester: 6472, 6480 Note: w/Drain Hole		
	 5200-129 For Delco PG260M PMGR Starter Lester: 6471 Note: w/Drain Hole		
	 5200-130 For Delco PG260M Starter Lester: 6449, 6470 Note: wo/Drain Hole		


4-1/2 i "	4 i "Mod I	4 i "Mod II	PMGR
 5200-207 For 4-1/2 i DD Starter OEM: C2OF-11001-A, C9FF-11001-A Lester: 3124, 3131, 3132, 3149, 3208	 5200-202 For 4 i Mod I DD Starter OEM: D4ZF-11001-AA, D6EF-11001-AA Lester: 3151	 5200-205 For 4 i Mod II DD Starter OEM: E25F-11001-AA, E2BF-11001-AA Lester: 3175, 3180, 3185, 3191	 5200-212 For PMGR Starter OEM: E9OF-11000-AA, F89U-11000-AA Lester: 3204, 3272, 3273
	 5200-203 For 4 i Mod I DD Starter OEM: E1EF-11001-AC, E2EF-11001-AA Lester: 3170M, 3179	 5200-206 For 4 i Mod II DD Starter OEM: E3EF-11001-AA, E6DF-11001-BA Lester: 3181, 3187, 3188, 3189, 3196	
	 5200-204 For 4 i Mod I DD Starter OEM: D7FZ-11002-A, E1ZF-11001-AA Lester: 3156	 5200-208 For 4-1/2 i Mod I, Mod II DD Starter OEM: D2HF-11001-E, E1AF-11001-BA Lester: 3152, 3160, 3168, 3172, 3174	
	 5200-200 For 4 i Mod II DD Starter OEM: E25F-11001-AA, E3TF-11001-AA Lester: 3133, 3180, 3185, 3191		


10MT ~ SD300		10MT ~ 27MT	28MT
			
5300-104 For Delco 40MT Series DD Starter Replaces: 1979434	5300-108 For Delco 42MT Series DD Starter Replaces: 1988093, 10473716, 19880934	5300-112 For Delco 10MT, 20MT, 22MT, 25MT, 27MT, SD300 Series DD Starter Replaces: 3300, 3601, 3664, 3691, 6305	5300-8400 For Delco 25MT, 28MT Series OSGR Starter
			
5300-105 For Delco 37MT, 41MT Series DD Starter Replaces: 1985231, 1987629, 10496568	5300-109 For Delco 42MT Series DD Starter Replaces: 1988436, 1988892, 1988998	5300-113 For Delco 25MT, 27MT Series DD Starter Replaces: 3725, 3764, 6343	5300-8401 For Delco 28MT Series DD
			
5300-106 For Delco 37MT, 41MT Series DD Starter Replaces: 10498654	5300-110 For Delco 50MT Series DD Starter Replaces: 1945857, 1983223, 1979598		5300-8402 For Delco 28MT Series Dry Clutch OSGR Starter
			
5300-107 For Delco 40MT Series DD Starter Replaces: 1979534			5300-8403 For Delco 28MT Series Wet Clutch OSGR Starter

5500- Shift Lever


Delco	Delco	Delco	Ford
 5500-100 For Delco 5MT,SD200 Series DD Starter Dim: 11mm Botton OD	 5500-107 For Delco 30MT,35MT,SD300 Series Internal Rotatable DD Starter Replaces: 1942245,D4906	 5500-115 For Delco SD210,SD260 Series DD Starter Replaces: 10473701,10496371	 5500-209 For Ford FMGR Starter Replaces: E90Z-11067-A,SZ-847
 5500-101 For Delco 5MT,SD200,SD250 Series DD Starter Dim: 8mm Botton OD	 5500-108 For Delco 37MT Series DD Starter Replaces: 1985237	 5500-117 For Delco PG260 Series FMGR Starter Replaces: 26mm Fork ID x 80mm L	
 5500-104 For Delco 8MT,10MT,15MT,20MT,25MT,27MT,SD300 Series DD Starter Replaces: 801433,D4910	 5500-109 For Delco 40MT,50MT Series DD Starter Replaces: 1945484		
 5500-105 For Delco 10MT,20MT,22MT,25MT,27MT,SD300 Series DD Starter Replaces: 1951567,D4908	 5500-110 For Delco 41MT,42MT Series DD Starter Replaces: 801433,D4910		

5500- Shift Lever Parts




Delco	Delco		
 5500-1201 For Delco 5MT,8MT,10MT,20MT,25MT, 27MT,SD200,SD205,SD250,SD255,SD300 Series DD Starter	 5500-1205 For Delco 30MT,35MT Series Internal Rotatable DD Starter		
 5500-1202 For Delco 37MT,40MT,41MT,42MT,50MT DD Starter Dim: 58.5mm L	 5500-1403 For Delco PG260 Series FMGR Starter		
 5500-1203 For Delco 30MT,35MT Series External Rotatable DD Starter Dim: 42.5mm L			
 5500-1204 For Delco 30MT,35MT Series Internal Rotatable DD Starter Dim: 33mm L			

Delco			
 5800-105 For Delco 20MT,22MT,25MT,27MT Series DD Starter Dim: 99mm L x 30mm W			
 5800-107 For Delco 35MT,40MT,42MT Series DD Starter Dim: 108mm L x 33mm W			
 5800-108 For Delco 37MT,41MT Series DD Starter Dim: 86mm L x 33mm W			
 5800-109 For Delco 50MT Series DD Starter Dim: 129mm L x 25mm W			


6600- Plunger And Parts

Delco	Delco	Delco	
 6600-1601 For Delco 5MT,8MT,10MT,20MT,22MT, 25MT,27MT,SD200,SD300 Series DD Starter Replaced: 1932200,1953041,10470783	 6600-1606 For Delco 37MT,41MT,42MT Series DD Starter Replaced: 1988140	 6601-1753 For Delco 40MT,50MT Series DD Starter Dim :No 10 Square Hole	
 6600-1602 For Delco 30MT,35MT Series External Rotatable DD Starter Replaced: 1851966	 6600-1607 For Delco 37MT,41MT,42MT Series DD Starter Replaced: 1988139,1988775		
 6600-1604 For Delco 40MT,50MT Series DD Starter	 6600-1610 For Delco 30MT,35MT Series External Rotatable DD Starter		
 6600-1605 For Delco 35MT,40MT,50MT Series DD Starter Replaced: 1948522			


6900- Brush Holder Assembly And Parts

Delco	Delco	Delco	Delco
 6900-101 For Delco 40MT Series Starter Replaces: 1948515	 6900-111 For Delco 37MT,41MT Series Starter Replaces: 10468891,10468892	 6901-106 Brush Holder & Rack Assy For Delco 5MT Series Starter Replaces: 1893924,10497180,10499232,D763,D781	 6901-1500 Brush Rack For Delco 5MT Series Starter
 6900-103 For Delco 42MT Series Starter Replaces: 1988121,1988122,1988439	 6900-114 For Delco PG260M Series FMGR Starter Replaces: 10475602	 6901-1200 Brush Holder For Delco 5MT Series Starter Replaces: 1893293	 6901-1503 Brush Holder Support For Delco 10MT,20MT,25MT Series Starter Replaces: 830803
 6900-108 For Delco 37MT Series Starter Replaces: 10468705,10468706,10469238,10470140		 6901-1201-1 Brush Holder - Ground For Delco 8MT,10MT,20MT,22MT,25MT,27MT,30MT,35MT Series DD Starter	 6901-1700 Brush Spring For Delco 5MT Series Starter
 6900-109 For Delco SD205,SD210,SD255,SD260 Series Starter Replaces: 10467615		 6901-1201-2 Brush Holder - Ground For Delco 8MT,10MT,20MT,22MT,25MT,27MT,30MT,35MT Series DD Starter	 6901-1704 Brush Spring For Delco 40MT,50MT Series Starter Replaces: 1861785

6900- Brush Holder Assembly And Parts

Delco	Ford	Ford	
 6901-1706 Brush Spring For Delco 37MT,42MT Series Starter Replaces: 1985314	 6901-2200 Brush Holder For Ford 4 1/2" Series Starter Replaces: C2DF-11061-A	 6901-2703 Brush Spring For Ford 4 1/2" Starter Replaces: C2DZ-11059-A, C3XF-11059-A	
	 6901-2203 Brush Holder For Ford 4-1/2" Solenoid Actuated Starter		
	 6901-2206 Brush Holder For Ford Permanent Gear Reduction Starter		
	 6901-2701 Brush Spring For Ford 4-1/2" Solenoid Actuated Starter		

7100- Gasket And Seal

Delco	Delco	Delco	Delco
 7100-1111 Shield - D.E. Frame For Delco 10MT Series Starter Replaces: 1957886	 7100-1309 Insulator - C.E. Terminal For Delco 37MT,40MT,41MT,42MT,50MT Series DD Starter Replaces: 1851604 Dim: 12.5mm ID	 7100-1319 Drain Tube - Field Case For Delco PG200,PG250 Series DD Starter Replaces: 10497538 Dim: Fit 8mm Dia.Hole	 7100-1331 Drain Tube - C.E. Frame For Delco PG260F2,PG260M Series PMGR Starter Replaces: 10475584 Dim: Fit 10.5mm Dia.Hole
 7100-1300 Grommet - Field Coil For Delco 5MT Series Starter Replaces: 1893303	 7100-1310 Insulator - F.C. Terminal For Delco 40MT,50MT Series DD Starter Replaces: 1988340 Dim: 12.5mm ID	 7100-1325 Plug - Shift Lever For Delco SD210,SD260 Series DD Starter Replaces: 10473703	 7100-1332 Grommet - Motor Lead For Delco SD205,SD55 Series DD Starter Replaces: 10487540
 7100-1306 Boot - Solenoid Plunger For Delco 30MT,35MT,40MT,50MT Series Starter Replaces: 801077	 7100-1313 Boot - Solenoid Plunger For Delco 37MT,42MT Series DD Starter Replaces: 1985243	 7100-1329 Grommet - Motor Lead For Delco PG260F2,PG260M Series PMGR Starter	
 7100-1308 Insulator - F.C. Terminal For Delco 37MT,41MT,42MT Series DD Starter Replaces: 1988340 Dim: 12.5mm ID	 7100-1316 Boot - Solenoid & D.E.Frame For Delco 10MT,20MT,22MT,25MT,27MT Series DD Starter Replaces: 1985243	 7100-1330 Plug - Shift Lever For Delco PG260M Series PMGR Starter	

7100- Gasket And Seal

Ford			
 7100-2307 Plug - Shift Lever For Ford FMGR, FMOSGR Starter Replaces: E9OZ-11A171-A  7100-2308 Plug			

Ford			
 7200-2104 Insulator - Brush Holder For Ford 4 ; *Mod I, 4-1/2 ; *Mod II, 4-1/2 ; *Mod II DD Starter  7200-7211 Insulator - Brush Holder For Ford 4 ; *Mod II Starter			



7600- Miscellaneous

Ford	Ford	Ford	Ford
 7600-2101 Shift Lever Cover For Ford 4-1/2 i*, 4-1/2 i* Mod I Starter Lester: 3124, 3131, 3132, 3135, 3149, 3152, 3153, 3154, 3155, 3157, 3160, 3165	 7600-2111 Shift Lever Cover For Ford 4 i* Mod II Starter Lester: 3179	 7601-2500 Contact Post For Ford 4-1/2 i* Starter Replaces: C2OZ-11176-A, C2OZ-11176-B	 7601-2509 Contact Post For Ford 4 i* Mod II Starter Lester: 3133, 3175, 3179, 3180, 3181, 3185, 3187, 3188, 3189, 3191, 3196, 3198
 7600-2103 Shift Lever Cover For Ford 4 i*, 4 i* Mod I Starter Lester: 3148, 3151, 3156, 3158, 3170, 3179		 7601-2503 Contact Post For Ford 4-1/2 i* Starter Replaces: D0AF-11177-A	 7601-2514 Contact Spring For Ford 4-1/2 i* Mod I, 4-1/2 i* Mod II DD Starter Lester: 3152, 3165, 3172, 3176
 7600-2104 Shift Lever Cover For Ford 4 i* Mod II Starter Lester: 3133, 3175, 3180, 3181, 3185, 3187, 3188, 3189, 3191, 3196, 3198		 7601-2505 Shift Lever Cover For Ford 4-1/2 i* Mod I, 4-1/2 i* Mod II Starter Replaces: D8AF-11177-AA	
 7600-2110 Shift Lever Cover For Ford 4-1/2 i* Mod II Starter Lester: 3168, 3169, 3172, 3174, 3176		 7601-2506 Contact Post For Ford 4 i* Starter Replaces: C2DF-11176-B, C2DZ-11076-B	

7600- Miscellaneous

Ford	Ford	Ford	Ford
 7602-2251 Support Bracket - C.E. Plate For Ford 4 i,*4 i,*Mod I Starter	 7602-2301 Retaining Flange - Field Coil For Ford 4 i,*4 i,*Mod I,4 i,*Mod II Starter Replaces: C2DF-11106-A	 7602-2305 Bracket - Ground Brush For Ford PMGR Starter	 7602-2801 Retainer For Ford Permanent Magnet G/R Starter Dim: 12mm ID x 17.8mm OD x 3.4mm H
 7602-2252 Support Bracket - C.E. Plate For Ford 4 i,*Mod I,4-1/2 i,*Mod II Starter Lester: 3170,3179,3181,3187,3188,3189,3196,3198	 7602-2302 Gear Retainer For Ford Permanent Magnet G/R Starter Replaces: E90Z-11A167-A, SM-477	 7602-2557 Field Coil Terminal For Ford 4 i,*Mod I,4-1/2 i,*Mod I,4-1/2 i,*Mod II DD Starter Dim: 60mm L	 7602-2804 Cup - D.E. Frame For Ford 4 i,*Mod I,4-1/2 i,*Mod I Starter Replaces: D0AZ-11K013-A
 7602-2253 Support Bracket - C.E. Plate For Ford 4 i,*Mod I,4 i,*Mod II,4-1/2 i,*Mod I,4-1/2 i,*Mod II Starter Lester: 3124,3185,3207,3208	 7602-2303 Pivot Pad - Shift Lever For Ford Permanent Magnet G/R Starter	 7602-2600 Connector - F.C to Solenoid	 7602-2808 Stationary Gear Retainer For Ford Permanent Magnet G/R Starter Dim: 15.6mm ID x 1.3mm T
 7602-2300 Retaining Flange - Field Coil For Ford 4-1/2 i,*4-1/2 i,*Mod I,4-1/2 i,*Mod II Starter Replaces: C0DF-11106-A	 7602-2304 Bracket - Brush Holder For Ford Permanent Magnet G/R Starter	 7602-2800 Stop Ring For Ford Permanent Magnet G/R Starter Dim: 10.5mm ID x 15.6mm OD x 2.7mm T	 7602-2809 Shaft Assembly For Ford Permanent Magnet G/R Starter




7600- Miscellaneous

Ford	Delco	Delco	Delco
 7602-2811 Stationary Gear Assembly For Ford Permanent Magnet G/R Starter Replace: E90Z-11A165-A, SM-476	 7603-1252 Connect - F.C. to Solenoid For Delco 30MT Internal Rotatable Starter Replaces: 1942249	 7603-1256 Connect - F.C. to Solenoid For Delco 50MT Series Starter Replaces: 1945862	 7604-1110 Brush Cover Plate For Delco 40MT Series Starter Replaces: 1948513
 7602-2814 Retainer - Magnet For Ford PMGR Starter	 7603-1253 Connect - F.C. to Solenoid For Delco 35MT Internal Rotatable Starter Replaces: 1946394	 7603-1261 Connect For Delco 42MT Series Starter Replaces: 1942249	 7604-1111 Clamp - Solenoid For Delco SD210, SD260 Series ID Starter Replaces: 10470161
 7602-2820 Shift - Reduction Gear For Ford Offset PMGR Starter Lester: 3263, 3264, 3266	 7603-1254 Connect - F.C. to Solenoid For Delco 35MT External Starter, 40MT Series Starter Replaces: 1945468		 7604-1113 Cover - Planetary Shaft Assy For Delco PG260 Series PMGR Starter Dim: 16.5mm ID x 70.5mm OD
 7602-2821 Reduction Gear For Ford Offset PMGR Starter Lester: 3263, 3264, 3266 Dim: 22T, 52mm Gear OD x 14.7mm L	 7603-1255 Connect - F.C. to Solenoid For Delco 42MT Series Starter Replaces: 10476198, 10498663, 1988134		 7604-1257 Clip - F.C. to Solenoid For Delco 37MT Series Starter Dim: 9.5mm ID

7600- Miscellaneous

Delco	Delco	Delco	Delco
 7604-1301 Retainer - Plunger Spring For Delco 30MT, 35MT, 37MT, 40MT, 42MT, 50MT Series Starter Dim: 1948520	 7604-1310 Mounting Shim For Delco 5MT, 10MT, SD210, SD250, SD260, SD300 Series Starter Dim: 2.0mm T	 7604-1802 Thrust Collar For Delco 5MT, 10MT Series Starter Dim: 12.16mm ID x 17.5mm OD	 7604-1855 Thrust Collar For Delco 5MT Series Starter Dim: 12mm ID x 19mm OD
 7604-1302 Retainer - Plunger Spring For Delco 30MT, 35MT, 37MT, 40MT, 42MT, 50MT Series Starter Replaces: 1948526	 7604-1550 Field Coil Terminal For Delco 37MT, 42MT Series Starter Dim: 1/4" -20 Internal Threads	 7604-1825 Oil Reservoir Cup For Delco 37MT, 42MT Series Starter Dim: 14.5mm OD	
 7604-1303 Field Coil Retainer For Delco 50MT Series Starter Dim: 50mm L	 7604-1618 Motor Lead For Delco PG260 Series PMGR Starter Dim: 103mm L	 7604-1838 Oil Reservoir Cup For Delco 35MT, 40MT, 50MT Series Starter Replaces: 1945862	
 7604-1305 Mounting Shim For Delco 10MT Series Starter Dim: 0.4mm T	 7604-1801 Retaining Ring For Delco 5MT, 10MT, PMGR Series Starter Dim: 1.6mm Wire Dia.	 7604-1844 Inspection Plug For Delco 30-35MT External Rotatable; 37MT, 40MT, 42MT, 50MT Series Starter	

7600- Miscellaneous

Ford	Delco		
 7605-2200 Retainer Sleeve For Ford 4-1/2 †, 4-1/2 † Mod I DD Starter Lester: 3124, 3131, 3135, 3165 Dim: 30mm W x 61mm L x 22.5mm H	 7606-1201 For Delco DD Starter OEM: 1108162, 1108949 Lester: 4433, 4658		
 7605-2203 Retainer Sleeve For Ford 4 †, *Mod, 4 †, *Mod I, 4 †, *Mod II DD Starter Lester: 3133, 3175, 3188, 3191, 3196 Dim: 28mm W x 58mm L x 22.7mm H			
 7605-2204 Retainer Sleeve For Ford 4-1/2 † Mod II DD Starter Lester: 3168, 3169, 3172, 3174, 3176 Dim: 30mm W x 61mm L x 21mm H			

8100- Commutator Drive End Frame

Ford			
 8100-1402 For Delco Automotive Generator  8100-1406 For Delco Tractor Motor-Generator			

8400- Hardware

 8400-1307 Thru Bolt Dim: 10-24 x 2-1/8 L Note: Hex Washer Head, 5/16 Drive Dog Point Zinc-Plated  8400-1414 Thru Bolt w/Extension Dim: 1/4-20 x 5-7/8 L, 1/4-20 x 3/4 L Ext. Note: Hex Washer Head, 3/8 Drive Plain Finish  8400-1415 Thru Bolt Dim: 1/4-20 x 5-15/16 L Note: Hex Washer Head, 3/8 Drive Plain Finish  8400-1418 Screw Dim: 1/4-20 x 7/8 L Note: Hex Washer Head, 5/16 Drive Attached Flat Washer Dog Point Black Oxide Finish	 8400-1500 Screw Dim: 3/8-16 x 5/8 L Note: Slotted Flat Head Black Oxide Finish  8400-1502 Screw Dim: 3/8-24 x 5/8 L Note: Phillips Flat Head Zinc-Yellow Plated  8400-1503 Screw Dim: 7/16-14 x 5/8 L Note: Square Drive Flat Head Plain Finish  8400-2700 Hex Nut Dim: 0.668-20 x 15/16 F x 5/16 T Note: Zinc-Yellow Plated	 8400-4606 Split Lock Washer Dim: 11/16 ID x 1-1/8 OD x 0.116 T Note: Zinc-Yellow Plated	
--	---	---	--

 8500-1302 Thru Bolt Dim: M5 x 0.8 x 66mm L Note: External Torx Head, E8 Drive Thread-Forming, Dog Point Zinc-Plated  8500-1317 Thru Bolt Dim: M5 x 0.8 x 126mm L Note: Hex Washer Head, 8mm Drive Zinc-Yellow Plated  8500-1320 Screw Dim: M5 x 0.8 x 10mm L Note: Hex Washer Head, 6mm Drive Dog Point Black Oxide Finish  8500-1328 Thru Bolt Dim: M6 x 1.0 x 180mm L Note: Hex Washer Head, 10mm Drive Zinc-Yellow Plated	 8500-1331 Screw Dim: M6 x 1.0 x 18mm L Note: Hex Washer Head, 8mm Drive Serrated Flange Zinc-Yellow Plated  8500-1332 Screw Dim: M5 x 0.8 x 14mm L Note: Hex Washer Head, 7mm Drive Zinc-Yellow Plated  8500-1338 Thru Bolt w/Extension Dim: M5 x 0.8 x 102mm L Note: Hex Washer Head, 10mm Drive Chamfered Point Zinc-Yellow Plated  8500-1339 Thru Bolt Dim: M5 x 0.8 x 102mm L Note: Hex Washer Head, 10mm Drive Chamfered Point Zinc-Yellow Plated	 8500-1341 Screw Dim: M6 x 1.0 x 48mm L Note: Phillips/Slot Pan Head Chamfered Point Attached Split Lock Washer Zinc-Yellow Plated  8500-1342 Screw Dim: M6 x 1.0 x 40mm L  8500-1343 Screw Dim: M6 x 1.0 x 30mm L  8500-1403 Thru Bolt w/Extension Dim: M7 x 1.0 x 40mm L M5 x 0.8 x 17mm L Ext. Note: Hex Washer Head, 8mm Drive Chamfered Point Zinc-Yellow Plated	 8500-2307 Hex Nut Dim: M6 x 1.0 x 10mm F x 5.8mm T Note: Top Lock Zinc-Yellow Plated  8500-2402 Hex Nut Dim: M8 x 1.25 x 13mm F x 4mm T Note: Zinc Plated  8500-2404 Hex Nut Dim: M8 x 1.25 x 13mm F x 2.3mm T Note: Zinc Plated  8500-2504 Hex Nut Dim: M10 x 1.5 x 17mm F x b12mm T Note: Zinc-Yellow Plated
---	---	---	---

8500- Hardware

 8500-2505 Hex Nut Dim: M10 x 1.5 x 17mm F x 6mm T Note: Zinc-Yellow Plated			
 8500-4501 Flat Washer Dim: 10mm ID x 23mm OD x 0.9mm T Note: Plain Finish			
 8500-4502 Flat Washer Dim: 10mm ID x 23mm OD x 0.2mm T Note: Plain Finish			